



PLC Integration of HT46C_2124

IO-Link service data function block + process data parser function for Beckhoff (TwinCAT 3.x) PLC systems in combination with a EtherCAT IO-Link Master

© 2021

Leuze electronic GmbH & Co. KG

In der Braike 1

D-73277 Owen / Germany

Phone: +49 7021 573-0

Fax: +49 7021 573-199

<http://www.leuze.com>

info@leuze.com

Table of Contents

1	Legal information.....	4
1.1	Disclaimer.....	4
2	About this document.....	5
2.1	Purpose of use.....	5
2.2	Target group.....	5
3	General use of function block.....	6
3.1	Short description.....	6
3.2	Calling and designation.....	6
3.3	Configuration.....	6
3.4	Method of function.....	7
3.5	Behavior when error occurs.....	7
4	Integration into the PLC project.....	8
5	Process data parser function.....	9
5.1	Calling and designation.....	9
5.2	Configuration.....	9
6	Error description.....	10
7	Data structures.....	11
8	Parameter descriptions.....	15
9	Technical specifications.....	18
9.1	General data.....	18

1 Legal information

1.1 Disclaimer

With the installation, copying or other use of this software product, you agree to the following conditions of use. If you do not agree with the conditions, do not install this software product. If you received the software product by means of download, terminate the download and delete all files that have already been downloaded.

This software product is protected by European and U.S. copyright law and international treaty provisions. You are in no way authorized to rent, lease, lend or sell the software or parts thereof to third parties.

Before you link the library, please close all unnecessary programs to avoid loss of data.

We highly recommend installing the software on a computer which is not already used in the production process or is needed for storing important data. It cannot be completely excluded that existing files will be changed or overwritten. Leuze electronic GmbH & Co. KG is not liable for damages and data loss that result from this installation or the failure to observe this warning notice.

NOTICE	
	<p>Observe the operating instructions!</p> <ul style="list-style-type: none">👉 Observe all safety notices provided in the operating instructions for these devices. Leuze electronic GmbH & Co. KG is not liable for personal injury and property damage that result from failure to comply with these safety notices.👉 Download the operating instructions for these devices at www.leuze.com.

2 About this document

Please read this chapter carefully before working with this documentation and the Leuze IO-Link device.

2.1 Purpose of use

These instructions have been designed for the technical personnel for the use of the IO-Link PLC blocks.

These instructions are intended to provide support during the commissioning of a Leuze IO-Link sensor using standard software from Siemens. The described module is part of this standard software.

2.2 Target group

These instructions are addressed to programming engineers and the operators of machines and systems, which are operated by one or several IO-Link devices. They also address people, who connect the IO-Link device via an IO-Link-Master-Gateway to a PLC-Control for data exchange.

3 General use of function block

3.1 Short description

The function block "FB_Leuze_IOL_ HT46C_2124" simplifies the usage of Leuze IO-Link devices on Beckhoff (TwinCAT 3.x) PLC controls. This FB supports IO-Link Masters which can be connected via EtherCAT to the PLC system.

The function block is device type-specific and thus only suitable for the appropriate Leuze IO-Link devices. The FB interprets the call-up of the acyclic service data between the PLC and the IO-Link device.

The IO-Link function block can only be used in combination with the listed helper functions / libraries.

3.2 Calling and designation



Fig. 3.1: Example of module call

3.3 Configuration

Tab. 3.1: Parameter IN

Parameter	Data type	Description
bExecute	Bool	Positive trigger: Start data transfer
bRW	Bool	Read or write the selected IO-Link parameter. FALSE: Read parameter TRUE: Write Parameter
nPort	T_AmsPort	Port number of the ADS device.
sNetId	T_AmsNetID	String containing the AMS network identifier of the target device to which the ADS command is directed. Beckhoff EL6224/EP6224: AoeNetId of the IO-Link Master
nIdxGroup	UDInt	Index group number.
tTimeOut	Time	Time, after a Timeout-Error is triggered.

Tab. 3.2: Parameter INOUT

Parameter	Data type	Description
stDeviceData	ST_Leuze_IOL_ HT46C_2124	Sensor data

See structure description of ST_Leuze_IOL_ HT46C_2124 in chapter 7.

Tab. 3.3: Parameter OUT

Parameter	Data type	Description
bDone	Bool	Indicates whether data is valid.

Parameter	Data type	Description
bBusy	Bool	Request in process. FALSE: Request is terminated TRUE: Request is being processed
bError	Bool	Error flag FALSE: No error TRUE: Error detected
stErrorCode	ST_Leuze_IOL_Error	Status of the function block

See structure description of ST_Leuze_IOL_Error in chapter 6.

3.4 Method of function

The function block uses the data structure "ST_Leuze_IOL_HT46C_2124". The PLC data structure contains the values of all IO-Link variables. Before you can use it, the structure must be instantiated by a data block. Each IO-Link FB parameter has a data point representing it in this data structure. This data point will be actualized every time a read request was executed successfully.

The desired parameters can be selected via the input variables. Depending on the device definition, IO-Link parameters are read or writable. The input variable must be "bRW" = FALSE to read parameter. The value that should be written can be defined in the data structure, as soon as the input parameter "bRW" = TRUE. You start each transfer by calling up the "FB_Leuze_IOL_HT46C_2124" with a positive trigger at the "bExecute" input. As long as there is no valid answer the output "bBusy" is TRUE. In the case that the chosen timeout period has elapsed a timeout error will be generated and the thread will be terminated. The "bDone" = TRUE output shows that the transmission was successful. The outputs retain there states as long as there is no new positive trigger at the "bExecute" input again.

The function block allows you to read or write multiple IO-Link parameters sequentially (multi-selection). Please note that it may happen, that a single parameter can not be written. The function block aborts at this point and it is possible, that the IO-Link device contains an inconsistent set of parameters.

3.5 Behavior when error occurs

An error bit (bError) is set and an error code (ST_Leuze_IOL_Error) generated, if there is a spurious input value or an incorrect input connection of the FB. In this case, no further processing is carried out, until the input has been corrected.

4 Integration into the PLC project

The function block "FB_Leuze_IOL_ HT46C_2124" is a part of the TwinCAT V3.x library. The library can be installed by using the Library Repository. Afterwards the library can be added to your project (References --> Add library...).

Integration step by step:

- Download the library
- Open the Library repository in Library Manager tab in Beckhoff TwinCAT
- Click Install... and select downloaded library
- Open Add library in Library Manager tab
- Find installed library under Leuze electronic GmbH + Co. KG

NOTICE	
	If several devices connect to the IO-Link Master, you can only exchange acyclic data (service data) with one device at the same time. Due this restriction, the service data communication blocks must to be blocked against each other.

5 Process data parser function

The function `F_Leuze_PD_HT46C_2124` simplifies the interpretation of composed IO-Link process data. This data is provided as a data structure on the PLC side. Some sensors supports different process data output. User must select mode of PD according to the sensors settings.

The function is device type-specific and thus only suitable for the appropriated Leuze IO-Link devices.

5.1 Calling and designation



Fig. 5.1: Example of process data parsing function call

5.2 Configuration

Tab. 5.1: Parameters

Parameter name	Declaration	Data type	Description
aProcessData	INPUT	ARRAY OF BYTE	Raw process data of the IO-Link device.
nPDMMode	INPUT	INT	Mode of the PD. User must select mode of PD according to the sensors settings.
bError	OUTPUT	BOOL	Error flag FALSE: No error TRUE: Error detected
F_Leuze_PD_HT46C_2124	OUTPUT	ST_Leuze_PD_HT46C_2124	Reference to the instance of the data structure ST_Leuze_PD_HT46C_2124. The structure includes the disaggregated values of the process data.

See structure description of `ST_Leuze_PD_HT46C_2124` in chapter 7.

6 Error description

The parameter "ErrorCode" can be interpreted using the PLC data type ST_Leuze_IOL_Error. This data type contains the following error information:

Tab. 6.1: ST_Leuze_IOL_Error description

Parameter name	Data type	Description
ErrorStatus.nBlockError	WORD	Error number representing FB where error occurred
ErrorStatus.nAdsReadError	UDINT	ADS read error code
ErrorStatus.nAdsWriteError	UDINT	ADS write error code
ErrorStatus.nIndex	INT	IO-Link index to which the error code refers
ErrorStatus.nSubIndex	INT	IO-Link sub-index to which the error code refers

Tab. 6.2: Error description for nBlockError

Error code (nBlockError)	Error description
0x0000	No error
0x8001	Time out error occurred
0x8002	No parameter selected
0x8003	Error in FB_Leuze_IOL_AdsReadWrite block

For additional information see the Beckhoff ADS Return Codes (<https://infosys.beckhoff.com>).

7 Data structures

Tab. 7.1: ST_Leuze_IOL_HT46C_2124

Parameter name	Data type	Description
stDeviceData.stSelection.stCommands.bDeviceReset	BOOL	[WRITE_ONLY] Device Reset
stDeviceData.stSelection.stCommands.bApplicationReset	BOOL	[WRITE_ONLY] Application Reset
stDeviceData.stSelection.stCommands.bRestoreFactorySettings	BOOL	[WRITE_ONLY] Restore Factory Settings
stDeviceData.stSelection.stCommands.bLightSwitching	BOOL	[WRITE_ONLY] light switching
stDeviceData.stSelection.stCommands.bDarkSwitching	BOOL	[WRITE_ONLY] dark switching
stDeviceData.stSelection.stCommands.bTimerOn	BOOL	[WRITE_ONLY] Timer on
stDeviceData.stSelection.stCommands.bTimerOff	BOOL	[WRITE_ONLY] Timer off
stDeviceData.stSelection.stCommands.bRestoreFactoryDefaults	BOOL	[WRITE_ONLY] Restore factory defaults
stDeviceData.stSelection.stCommands.bSaveCurrentParametersToDevice	BOOL	[WRITE_ONLY] Save current parameters to device
stDeviceData.stSelection.stCommands.bEnableNormalProcessDataOutput	BOOL	[WRITE_ONLY] Enable Normal Process Data Output
stDeviceData.stSelection.stCommands.bEnableAdcSignalProcessDataOutput	BOOL	[WRITE_ONLY] Enable ADC Signal Process Data Output
stDeviceData.stSelection.bStandardCommand	BOOL	[WRITE_ONLY]
stDeviceData.stSelection.stDirectParameters1.bAll	BOOL	[READ_WRITE] all parameters of complex data type
stDeviceData.stSelection.stDirectParameters1.bReserved_1	BOOL	[READ_ONLY]
stDeviceData.stSelection.stDirectParameters1.bMasterCycleTime	BOOL	[READ_ONLY]
stDeviceData.stSelection.stDirectParameters1.bMinCycleTime	BOOL	[READ_ONLY]
stDeviceData.stSelection.stDirectParameters1.bMSequenceCapability	BOOL	[READ_ONLY]
stDeviceData.stSelection.stDirectParameters1.bIoLinkVersionId	BOOL	[READ_ONLY]
stDeviceData.stSelection.stDirectParameters1.bProcessDataInputLength	BOOL	[READ_ONLY]
stDeviceData.stSelection.stDirectParameters1.bProcessDataOutputLength	BOOL	[READ_ONLY]
stDeviceData.stSelection.stDirectParameters1.bVendorId1	BOOL	[READ_ONLY]
stDeviceData.stSelection.stDirectParameters1.bVendorId2	BOOL	[READ_ONLY]
stDeviceData.stSelection.stDirectParameters1.bDeviceId1	BOOL	[READ_ONLY]
stDeviceData.stSelection.stDirectParameters1.bDeviceId2	BOOL	[READ_ONLY]

Parameter name	Data type	Description
stDeviceData.stSelection.stDirectParameters1.bDeviceId3	BOOL	[READ_ONLY]
stDeviceData.stSelection.stDirectParameters1.bReserved_13	BOOL	[READ_ONLY]
stDeviceData.stSelection.stDirectParameters1.bReserved_14	BOOL	[READ_ONLY]
stDeviceData.stSelection.stDirectParameters1.bReserved_15	BOOL	[READ_ONLY]
stDeviceData.stSelection.stDp.bAll	BOOL	[READ_WRITE] all parameters of complex data type
stDeviceData.stData.stCommands.nDeviceReset	UINT	[WRITE_ONLY] Device Reset
stDeviceData.stData.stCommands.nApplicationReset	UINT	[WRITE_ONLY] Application Reset
stDeviceData.stData.stCommands.nRestoreFactorySettings	UINT	[WRITE_ONLY] Restore Factory Settings
stDeviceData.stData.stCommands.nLightSwitching	UINT	[WRITE_ONLY] light switching
stDeviceData.stData.stCommands.nDarkSwitching	UINT	[WRITE_ONLY] dark switching
stDeviceData.stData.stCommands.nTimerOn	UINT	[WRITE_ONLY] Timer on
stDeviceData.stData.stCommands.nTimerOff	UINT	[WRITE_ONLY] Timer off
stDeviceData.stData.stCommands.nRestoreFactoryDefaults	UINT	[WRITE_ONLY] Restore factory defaults
stDeviceData.stData.stCommands.nSaveCurrentParametersToDevice	UINT	[WRITE_ONLY] Save current parameters to device
stDeviceData.stData.stCommands.nEnableNormalProcessDataOutput	UINT	[WRITE_ONLY] Enable Normal Process Data Output
stDeviceData.stData.stCommands.nEnableAdcSignalProcessDataOutput	UINT	[WRITE_ONLY] Enable ADC Signal Process Data Output
stDeviceData.stData.nStandardCommand	UINT	[WRITE_ONLY]
stDeviceData.stData.stDirectParameters1.nReserved_1	UINT	[READ_ONLY]
stDeviceData.stData.stDirectParameters1.nMasterCycleTime	UINT	[READ_ONLY]
stDeviceData.stData.stDirectParameters1.nMinCycleTime	UINT	[READ_ONLY]
stDeviceData.stData.stDirectParameters1.nMSequenceCapability	UINT	[READ_ONLY]
stDeviceData.stData.stDirectParameters1.nIoLinkVersionId	UINT	[READ_ONLY]
stDeviceData.stData.stDirectParameters1.nProcessDataInputLength	UINT	[READ_ONLY]
stDeviceData.stData.stDirectParameters1.nProcessDataOutputLength	UINT	[READ_ONLY]
stDeviceData.stData.stDirectParameters1.nVendorId1	UINT	[READ_ONLY]
stDeviceData.stData.stDirectParameters1.nVendorId2	UINT	[READ_ONLY]

Parameter name	Data type	Description
stDeviceData.stData.stDirectParameters1.nDeviceId1	UINT	[READ_ONLY]
stDeviceData.stData.stDirectParameters1.nDeviceId2	UINT	[READ_ONLY]
stDeviceData.stData.stDirectParameters1.nDeviceId3	UINT	[READ_ONLY]
stDeviceData.stData.stDirectParameters1.nReserved_13	UINT	[READ_ONLY]
stDeviceData.stData.stDirectParameters1.nReserved_14	UINT	[READ_ONLY]
stDeviceData.stData.stDirectParameters1.nReserved_15	UINT	[READ_ONLY]
stDeviceData.stData.stDp.nOffLimit	UINT	[READ_WRITE] Off Limit
stDeviceData.stData.stDp.nOnLimit	UINT	[READ_WRITE] On Limit
stDeviceData.stData.stDp.bKeyLock	BOOL	[READ_WRITE] Key Lock; IO-Link Parameter overrides IN2 Input/PD
stDeviceData.stData.stDp.nQ2LogicFunction	UINT	[READ_WRITE]
stDeviceData.stData.stDp.nDelayFunctionInternalDelayUnit	UINT	[READ_WRITE] Operating mode of the internal delay unit
stDeviceData.stData.stDp.nTimeBaseInternalDelayUnit	UINT	[READ_WRITE] 1ms, 10ms, 100ms, 1000ms
stDeviceData.stData.stDp.nMultiplicationFactorForTimeBaseInternalDelayUnit	UINT	[READ_WRITE] 1-15
stDeviceData.stData.stDp.bEasyTune	BOOL	[READ_WRITE] Enable EasyTune
stDeviceData.stData.stDp.bLightDarkSwitching	BOOL	[READ_WRITE] Light/Dark Switching: adjusting the switching behavior of the switching output
stDeviceData.stData.stDp.bInternalDelayUnitBasedOnObject	BOOL	[READ_WRITE] Enable Internal Delay Unit
stDeviceData.stData.stDp.nTeachValue2	UINT	[READ_WRITE]
stDeviceData.stData.stDp.nPdiContent	UINT	[READ_ONLY]
stDeviceData.stData.stDp.bStatusCommand	BOOL	[READ_ONLY] Value is re-read after new command. All status bits are valid after finished command.
stDeviceData.stData.stDp.bCommandAccepted	BOOL	[READ_ONLY]
stDeviceData.stData.stDp.bTeachError	BOOL	[READ_ONLY]
stDeviceData.stData.stDp.bLastValuesRestored	BOOL	[READ_ONLY]
stDeviceData.stData.stDp.bReceptionLevelTooHigh	BOOL	[READ_ONLY]
stDeviceData.stData.stDp.bReceptionLevelTooLow	BOOL	[READ_ONLY]

Tab. 7.2: ST_Leuze_PD_HT46C_2124

Parameter name	Data type	Description
ST_Leuze_PD_HT46C_2124.stMode_0.cQ	BOOL	
ST_Leuze_PD_HT46C_2124.stMode_0.bWarning	BOOL	
ST_Leuze_PD_HT46C_2124.stMode_0.bStatus	BOOL	
ST_Leuze_PD_HT46C_2124.stMode_1.cQ	BOOL	
ST_Leuze_PD_HT46C_2124.stMode_1.nReceivedSignal	UINT	

8 Parameter descriptions

Tab. 8.1: IODD parameter descriptions

(AR - Access Rights, R - Read only, W - Write only, RW - Read and Write, NS - Not specified)

Parameter	Index	Subindex	Data type	Default	AR	Description
Commands			RecordT		W	
Device Reset			UIntegerT	128	W	Device Reset
Application Reset			UIntegerT	129	W	Application Reset
Restore Factory Settings			UIntegerT	130	W	Restore Factory Settings
light switching			UIntegerT	161	W	light switching
dark switching			UIntegerT	162	W	dark switching
Timer on			UIntegerT	163	W	Timer on
Timer off			UIntegerT	164	W	Timer off
Restore factory defaults			UIntegerT	172	W	Restore factory defaults
Save current parameters to device			UIntegerT	173	W	Save current parameters to device
Enable Normal Process Data Output			UIntegerT	174	W	Enable Normal Process Data Output
Enable ADC Signal Process Data Output			UIntegerT	191	W	Enable ADC Signal Process Data Output
Direct Parameters 1	0	0	RecordT		RW	
Reserved	0	1	UIntegerT		R	
Master Cycle Time	0	2	UIntegerT	0	R	
Min Cycle Time	0	3	UIntegerT	23	R	
M-Sequence Capability	0	4	UIntegerT	0	R	
IO-Link Version ID	0	5	UIntegerT	17	R	
Process Data Input Length	0	6	UIntegerT	72	R	
Process Data Output Length	0	7	UIntegerT	1	R	
Vendor ID 1	0	8	UIntegerT	1	R	
Vendor ID 2	0	9	UIntegerT	82	R	
Device ID 1	0	10	UIntegerT	0	R	
Device ID 2	0	11	UIntegerT	16	R	

Parameter	Index	Subindex	Data type	Default	AR	Description
Device ID 3	0	12	UIntegerT	2	R	
Reserved	0	13	UIntegerT		R	
Reserved	0	14	UIntegerT		R	
Reserved	0	15	UIntegerT		R	
Standard Command	0	16	UIntegerT		W	(0 ... 63): Reserved 128: Device Reset 129: Application Reset 130: Restore Factory Settings (131 ... 159): Reserved 161: light switching 162: dark switching 163: Timer on 164: Timer off 172: Restore factory defaults 173: Save current parameters to device 174: Enable Normal Process Data Output 191: Enable ADC Signal Process Data Output
DP	1	0	RecordT		RW	
Off Limit	1	2	UIntegerT		RW	Off Limit
On Limit	1	3	UIntegerT		RW	On Limit
Key Lock	1	6	BooleanT	1	RW	Key Lock; IO-Link Parameter overrides IN2 Input/PD False: Disabled True: Enabled
Q2 logic function	1	8	UIntegerT	0	RW	0: Inverted Switching Output 1: Switching Output 2: Warning Output
Delay Function (internal delay unit)	1	10	UIntegerT	1	RW	Operating mode of the internal delay unit 0: On delay 1: Off delay 2: pulse stretching 3: pulse suppression
Time base (internal delay unit)	1	11	UIntegerT	1	RW	1ms, 10ms, 100ms, 1000ms 0: 1ms 1: 10ms 2: 100ms 3: 1000ms
Multiplication factor for time base (internal delay unit)	1	12	UIntegerT	1	RW	1-15
EasyTune	1	16	BooleanT		RW	Enable EasyTune False: Disabled True: Enabled

Parameter	Index	Subindex	Data type	Default	AR	Description
Light/Dark Switching	1	18	BooleanT	0	RW	Light/Dark Switching: adjusting the switching behavior of the switching output False: light switching True: dark switching
Internal Delay Unit (based on object)	1	20	BooleanT	0	RW	Enable Internal Delay Unit False: Disabled True: Enabled
Teach Value 2	1	25	UIntegerT		RW	
PDI Content	1	26	UIntegerT	0	R	0: Switching Signal and Status 1: Analog ADC value and Switching Signal
Status Command	1	32	BooleanT	0	R	Value is re-read after new command. All status bits are valid after finished command. False: finished True: running
Command accepted	1	33	BooleanT	0	R	False: no True: yes
Teach Error	1	36	BooleanT	0	R	False: no True: yes
Last values restored	1	37	BooleanT	0	R	False: no True: yes
Reception level too high	1	38	BooleanT	0	R	False: no True: yes
Reception level too low	1	39	BooleanT	0	R	False: no True: yes

9 Technical specifications

9.1 General data

Tab. 9.1: Sensor and IODD version

IODD version	V1.0
IODD release date	2018-9-12
Device family	BR 46C
Device ID	2124
Device name	HT46CI/LP-M12
Device variants	HT46C IO-Link (BR46C)