

Original operating instructions

BCL 8

Bar code reader with integrated decoder



© 2022

Leuze electronic GmbH + Co. KG

In der Braike 1

D-73277 Owen / Germany

Phone: +49 7021 573-0

Fax: +49 7021 573-199

<http://www.leuze.com>

info@leuze.de

1	General information	6
1.1	Explanation of symbols	6
1.2	Declaration of Conformity	6
2	Safety	7
2.1	Intended use	7
2.2	Foreseeable misuse	8
2.3	Competent persons	8
2.4	Exemption of liability	8
2.5	Laser safety notices	8
3	Description	10
3.1	The BCL 8 bar code reader	10
3.2	Stand-alone operation	10
3.3	Daisy chain network	10
4	Technical data	12
4.1	General specifications BCL 8	12
4.2	LED indicators	13
4.3	Dimensioned and connection drawings	14
4.4	Optical data	16
4.4.1	Type overview	16
4.4.2	Reading fields	16
5	Accessories/order codes	18
5.1	Accessories overview	18
5.2	MA 8.1 connection unit	19
5.2.1	Electrical connection MA 8.1	20
5.2.2	MA 8.1 - PWR IN HOST/RS232 - voltage supply and RS 232	20
5.2.3	MA 8.1 - SW IN/OUT – switching input and switching output	21
5.2.4	MA 8.1 - BCL - connecting the BCL 8 to the MA 8.1	22
5.3	Connection unit MA 8-01	23
5.3.1	MA 8-01 - PWR IN HOST/RS485 - Voltage supply and RS 485	24
5.3.2	MA 8-01 - SW IN/OUT - switching input and switching output	24
5.3.3	MA 8-01 - BCL - connecting the BCL 8 to the MA 8-01	25
5.3.4	Termination of the RS 485 interface	26
5.4	Mounting accessories	26
6	Installation	27
6.1	Storage, transportation	27
6.2	Mounting	27
6.2.1	Device arrangement	28
6.3	Connecting	29
6.3.1	Connecting the BCL 8	29
6.3.2	Connecting the switching input/output	29
6.3.3	Cable lengths	31
6.4	Disassembling, packing, disposing	31
7	Commissioning	32
7.1	Measures to be performed prior to the initial commissioning	32
7.2	Function Test	32
7.3	Setting the parameters	32
7.3.1	Parameter sets	32



7.3.2	Service operating mode	33
8	Operation	34
8.1	Display elements	34
8.2	Error handling	34
9	Configuration and diagnostics software - Sensor Studio	35
9.1	System requirements	35
9.2	Installing Sensor Studio	36
9.2.1	Downloading configuration software	36
9.2.2	Installing the Sensor Studio FDT frame	36
9.2.3	Installing communication DTM and device DTM	36
9.2.4	Connecting device to PC	36
9.3	Starting Sensor Studio	36
9.4	Exiting Sensor Studio	38
9.5	Configuration parameters	38
9.5.1	Decode tab	38
9.5.2	Output tab	41
9.5.3	Control tab	43
9.5.4	Host interface tab	44
9.5.5	Reference code tab	45
9.5.6	Switching input tab	46
9.5.7	Switch tab	47
9.6	Diagnosis	48
9.7	Firmware Reload	48
10	Starting up the device – Configuration	50
10.1	Measures to be performed prior to the initial commissioning	50
10.2	Starting the device	50
10.2.1	Power-on test	50
10.2.2	Interface	50
10.2.3	Online commands	50
10.2.4	Problems	50
10.3	Starting up with factory settings	50
10.4	Setting the configuration parameters	51
10.4.1	Service mode	51
10.4.2	Parameter sets	52
11	Online commands	53
11.1	Overview of commands and parameters	53
11.1.1	General online commands	53
11.1.2	Online commands for system control	57
11.1.3	'Online' commands for parameter set operations	58
12	Maintenance	61
12.1	General maintenance information	61
12.2	Repairs, servicing	61
12.3	Diagnostics and troubleshooting	61
12.4	Service and support	62
12.5	Example bar code label types	63


Figure 2.1:	Laser apertures, laser warning signs.....	9
Figure 3.1:	Device construction of the BCL 8	10
Table 4.1:	Technical data	12
Table 4.2:	LED indicators	13
Figure 4.1:	Dimensioned drawing BCL 8 S M ...0, BCL 8 S N ...0 with lateral beam exit.....	14
Figure 4.2:	Dimensioned drawing BCL 8 S M ...2, BCL 8 S N ...2 with front beam exit	15
Table 4.3:	Type overview - M optics	16
Table 4.4:	Type overview - N optics	16
Figure 4.3:	Reading field of BCL 8 S M ... with M optics (medium density)	17
Figure 4.4:	Reading field of BCL 8 S N ... with N optics (high density)	17
Table 5.1:	Accessories/order codes	18
Figure 5.1:	Photo and dimensioned drawing of the MA 8.1 connection unit.....	19
Figure 5.2:	Electrical connection MA 8.1	20
Figure 5.3:	MA 8.1 - Pin assignment PWR IN HOST/RS232.....	20
Figure 5.4:	MA 8.1 - Pin assignment SW IN/OUT.....	21
Figure 5.5:	Connection of the switching input/output of the MA 8.1.....	21
Figure 5.6:	MA 8.1 - Pin assignment BCL.....	22
Figure 5.7:	Pin assignment - MA 8-01	23
Figure 5.8:	MA 8-01 - Pin assignment PWR IN HOST/RS485	24
Figure 5.9:	MA 8-01 - Pin assignment SW IN/OUT	24
Figure 5.10:	Electrical connection MA 8-01	25
Figure 5.11:	MA 8-01 - Pin assignment BCL	25
Figure 5.12:	Termination of the RS 485 interface in the MA 8-01.....	26
Figure 5.13:	Universal rod mounting system for BCL 8	26
Figure 6.1:	BCL 8 device name plate.....	27
Figure 6.2:	Definition of the BCL 8 reading angles	28
Figure 6.3:	BCL 8 pin assignment.....	29
Table 6.1:	Wiring description BCL 8	29
Figure 6.4:	Switching input for BCL 8 connection version 1 (standard setting)	30
Figure 6.5:	Switching input for BCL 8 connection version 2 (setting "inverted")	30
Figure 6.6:	Switching output BCL 8	30
Table 6.2:	Cable lengths.....	31
Figure 7.1:	Bar code label "Service"	33
Figure 7.2:	Connecting the RS 232 interface to a PC or terminal.....	33
Table 9.1:	System requirements for <i>Sensor Studio</i> installation	35
Figure 9.1:	Device selection for the BCL 8	37
Figure 9.2:	Configuration project: Device manager for BCL 8	37
Figure 9.3:	Decode tab	38
Figure 9.4:	Standard settings of the Properties dialog box (SYMBOLGY PROPERTIES)	39
Figure 9.5:	Standard settings of the Properties dialog box (COMMON PROPERTIES).....	40
Figure 9.6:	<i>Output</i> tab (OUTPUT FORMAT).....	41
Figure 9.7:	Properties dialog box (COMMON PROPERTIES).....	42
Figure 9.8:	<i>Control</i> tab	43
Figure 9.9:	<i>Host Interface</i> tab	44
Figure 9.10:	Standard settings of the Properties dialog box (FRAMING PROTOCOL).....	44
Figure 9.11:	<i>Reference Code</i> tab.....	45
Figure 9.12:	Standard settings of the Properties dialog box (PROPERTIES)	46
Figure 9.13:	<i>Switching input</i> tab.....	46
Figure 9.14:	<i>Switching output</i> tab	47
Figure 9.15:	<i>Diagnosis</i> tab	48
Figure 9.16:	Firmware Reload	49
Figure 10.1:	Bar code label "Service"	52
Figure 12.1:	Example bar code label types.....	63

1 General information

1.1 Explanation of symbols


The symbols used in this technical description are explained below.

 ATTENTION!	
	This symbol precedes text messages which must strictly be observed. Failure to observe the provided instructions could lead to personal injury or damage to equipment.

<i>NOTE</i>	
	This symbol indicates text passages containing important information.

1.2 Declaration of Conformity

The BCL 8 bar code reader and the optional MA 8.1 connection unit have been developed and produced in accordance with the applicable European standards and directives.

<i>NOTE</i>	
	The corresponding declaration of conformity can be requested from the manufacturer.

The manufacturer of the product, Leuze electronic GmbH & Co. KG in D-73277 Owen, possesses a certified quality assurance system in accordance with ISO 9001.



2 Safety

This sensor was developed, manufactured and tested in line with the applicable safety standards. It corresponds to the state of the art.

2.1 Intended use




The BCL 8 bar code reader is designed as a stationary scanner with integrated decoder for all common bar codes used for automatic object detection.

The optional MA 8.1 connection unit is intended for the easy connection of a bar code reader of type BCL 8.

Areas of application

The BCL 8 bar code reader with optional MA 8.1 connection unit is designed especially for the following fields of application:

- Labeling and packaging machines
- Automatic analyzers
- For space-critical bar code reading tasks
- Material flow
- Pharmaceutical industry
- Robotics and automation technology


⚠ CAUTION!	
	<p>Observe intended use!</p> <p>↳ Only operate the device in accordance with its intended use.</p> <p>The protection of personnel and the device cannot be guaranteed if the device is operated in a manner not complying with its intended use.</p> <p>Leuze electronic GmbH + Co. KG is not liable for damages caused by improper use.</p> <p>↳ Read the technical description before commissioning the device.</p> <p>Knowledge of this technical description is an element of proper use.</p>
NOTE	
	<p>Comply with conditions and regulations!</p> <p>↳ Observe the locally applicable legal regulations and the rules of the employer's liability insurance association.</p>
⚠ ATTENTION!	
	<p>For UL applications, use is only permitted in Class 2 circuits in accordance with the NEC (National Electric Code).</p>

2.2 Foreseeable misuse

Any use other than that defined under "Intended use" or which goes beyond that use is considered improper use.

In particular, use of the device is not permitted in the following cases:

- in rooms with explosive atmospheres
- as stand-alone safety component in accordance with the machinery directive ¹⁾
- for medical purposes

NOTE	
	<p>Do not modify or otherwise interfere with the device!</p> <p>↳ Do not carry out modifications or otherwise interfere with the device. The device must not be tampered with and must not be changed in any way. The device must not be opened. There are no user-serviceable parts inside. Repairs must only be performed by Leuze electronic GmbH + Co. KG.</p>

2.3 Competent persons

Connection, mounting, commissioning and adjustment of the device must only be carried out by competent persons.

Prerequisites for competent persons:

- They have a suitable technical education.
- They are familiar with the rules and regulations for occupational safety and safety at work.
- They are familiar with the technical description of the device.
- They have been instructed by the responsible person on the mounting and operation of the device.

Certified electricians

Electrical work must be carried out by a certified electrician.

Due to their technical training, knowledge and experience as well as their familiarity with relevant standards and regulations, certified electricians are able to perform work on electrical systems and independently detect possible dangers.



In Germany, certified electricians must fulfill the requirements of accident-prevention regulations DGUV V3 (e.g. electrician foreman). In other countries, there are respective regulations that must be observed.

2.4 Exemption of liability

Leuze electronic GmbH + Co. KG is not liable in the following cases:

- The device is not being used properly.
- Reasonably foreseeable misuse is not taken into account.
- Mounting and electrical connection are not properly performed.
- Changes (e.g., constructional) are made to the device.

2.5 Laser safety notices

 ATTENTION, LASER RADIATION – CLASS 1 LASER PRODUCT	
	<p>The device satisfies the requirements of IEC/EN 60825-1:2014 safety regulations for a product of laser class 1 and complies with 21 CFR 1040.10 except for conformance with IEC 60825-1 Ed. 3., as described in Laser Notice No. 56, dated May 8, 2019.</p> <p>↳ Observe the applicable statutory and local laser protection regulations.</p> <p>↳ The device must not be tampered with and must not be changed in any way. There are no user-serviceable parts inside. Repairs must only be performed by Leuze electronic GmbH + Co. KG.</p>

¹⁾ Use as safety-related component within the safety function is possible, if the component combination is designed correspondingly by the machine manufacturer.




Figure 2.1: Laser apertures, laser warning signs

3 Description

Device construction of the BCL 8




Figure 3.1: Device construction of the BCL 8

3.1 The BCL 8 bar code reader

The BCL 8 bar code reader is a laser scanner with integrated decoder for all commonly used bar codes, e.g. 2/5 Interleaved, Code 39, Code 128, EAN etc., with an extremely small housing.

The many possible configurations of the device allow it to be adapted to a multitude of reading tasks. Due to the small dimensions of the unit and its large reading field, the BCL 8 may also be used in highly constrained spaces.

For information on technical data and characteristics, refer to Chapter 4.

3.2 Stand-alone operation

The BCL 8 bar code reader is operated as a "stand-alone" device. It is equipped with a 5-wire cable with open ends or a 5-pin M12 connector for the electrical connection of the supply voltage, the interface and the switching input.

With MA 8.1 connection unit

The MA 8.1 connection unit simplifies the electrical installation of the bar code reader in stand-alone operation with an **RS 232 interface**.

For details on the connection units, see Chapter 5.

With MA 8-01 connection unit

The MA 8-01 connection unit simplifies the electrical installation of the bar code reader in stand-alone operation with an **RS 485 interface**.

For details on the connection units, see Chapter 5.

3.3 Daisy chain network

A daisy chain is a network based on the RS 232 interface. All devices, which consist of a transmitter and a receiver, are connected to one another to form a ring. The transmitter of one device is directly connected to the receiver of the next device until all devices are connected together to form a ring. One device performs the task of the host system.

Ideally, all BCL 8 devices are to be connected to one another with MA 8.1 connection units so that:

- the voltage supply of the BCL 8/MA 8.1 is ensured.
- TxD to RxD of the RS 232 is established from one BCL 8 to the next (host).
- the switching outputs and inputs are connected (optional).

A maximum of seven BCL 8 devices may be operated in the daisy chain together with one host. Further information is available from your Leuze sales office.

4 Technical data

4.1 General specifications BCL 8

Optical data

Light source	Laser diode
Laser class	1 acc. to IEC/EN 60825-1:2014 and U.S. 21 CFR 1040.10 with Laser Notice No. 56
Wavelength	655nm
Scanning rate	M optics: 600 scans/s N optics: 500 scans/s
Resolution	M optics: m = 0.150 ... 0.500 mm / 6 ... 20 mil N optics: m = 0.127 ... 0.400 mm / 5 ... 16 mil
Beam deflection	Via rotating polygon wheel
Beam exit	Front, alternatively on the side with deflection mirror (105°)
Reading distance	See reading fields
Reading field opening	See reading fields
Code types	2/5 Interleaved, Code 39, Code 128, EAN 128, EAN/UPC, EAN Addendum, Codabar, Pharma Code, Code 93
Software features	Selectable output format, autoConfig, autoReflAct, reference code comparison, multiple read, real time decoding, adjustment mode, control of switching input or switching output, etc.

Electrical data

Interface type	RS 232, freely configurable
Baud rate	4800 ... 57600 Bd
Data formats	Data bits: 7, 8 Parity: none, even, odd Stop bit: 1, 2
Protocols	Framing protocol with/without acknowledgment Software handshake X ON / X OFF
Service interface	RS 232 with fixed data format, 9600Bd, 8 data bits, no parity, 1 stop bit <STX> <data> <CR><LF>
Ports	1 switching input 5VDC or 1 switching output 5 ... 30V, 20mA
LEDs	1 device status 1 read status
Operating voltage	4.75 ... 5.5VDC, protection class III - PELV ¹⁾ (Protective Extra Low Voltage)
Current consumption	Max. 250 mA (2 W power supply unit recommended)

Mechanical data

Degree of protection	IP 67
Connection type	M12 connector, 5-pin, turnable or Fixed cable, 2 m long, 5 x 0.25 mm ²
Weight	70g
Dimensions (H x W x D)	Front beam exit: 48 x 40.3 x 15 mm Lateral beam exit: 48 x 58 x 17.4 mm
Housing	Metal (diecast zinc)

Environmental data

Ambient temp. (operation/storage)	0°C ... +40°C/-20°C ... +60°C
Air humidity	Max. 90% rel. humidity, non-condensing
Vibration	IEC 60068-2-6, test Fc
Shock	IEC 60068-2-27, test Ea

Table 4.1: Technical data

Electromagnetic compatibility Conformity	EN 55022, IEC 61000-4-2, -3, -4 and -6, CE, FCC Class B, CDRH
Certifications	UL 60950-1, C22.2 No. 60950-1 ^{1) 2)}

Table 4.1: Technical data

- 1) For UL applications: use is permitted exclusively in Class 2 circuits according to NEC
- 2) These bar code readers shall be used with UL Listed Cable assemblies rated 30V, 0.5A min, in the field installation, or equivalent (categories: CYJV/CYJV7 or PVVA/PVVA7)

4.2 LED indicators

Two, 3-color LEDs on the top of the housing indicate the device and read status:

LED	Color	Meaning
Status LED	Green, flashing	Initialization phase
	Green, continuous	Operational readiness
	Red, flashing (200 ms)	Warning
	Red, continuous	Error, no function
	Orange, flashing (200 ms)	Service operation
Decode LED	Green (200ms on)	Reading successful
	Red (200ms off)	No read result
	Orange, continuous	Reading gate active

Table 4.2: LED indicators

4.3 Dimensioned and connection drawings

BCL 8 S M ...0, BCL 8 S N ...0 with lateral beam exit





Figure 4.1: Dimensioned drawing BCL 8 S M ...0, BCL 8 S N ...0 with lateral beam exit

4.4 Optical data

NOTE	
	Please note that the size of the bar code module influences the maximum reading distance and the width of the reading field. Therefore, when selecting a mounting location and/or the bar code label, take into account the different reading characteristics of the scanner with various bar code modules.

For different reading task and connection requirements, the BCL 8 is available in various models (see chapter 4.4.1 "Type overview").

4.4.1 Type overview

BCL 8 with M optics

Type	Operating range	Module/ resolution [mm]	Connection	Scanner type/ Beam exit	Part no.
BCL 8 S M 100	Up to 160mm	0.15 ... 0.5	M12 connector	Single line/ Lateral	50040229
BCL 8 S M 102				Single line/ Front	50038949
BCL 8 S M 550			Fixed cable (2m)	Single line/ Lateral	50040230
BCL 8 S M 552				Single line/ Front	50038948


Table 4.3: Type overview - M optics

BCL 8 with N optics

Type	Operating range	Module/ resolution [mm]	Connection	Scanner type/ Beam exit	Part no.
BCL 8 S N 100	Up to 120mm	0.125 ... 0.4	M12 connector	Single line/ Lateral	50105417
BCL 8 S N 102				Single line/ Front	50105418
BCL 8 S N 550			Fixed cable (2m)	Single line/ Lateral	50105419
BCL 8 S N 552				Single line/ Front	50105420

Table 4.4: Type overview - N optics

4.4.2 Reading fields

NOTE	
	Please note that the actual reading fields are also influenced by factors such as labeling material, printing quality, reading angle, printing contrast etc., and may thus deviate from the reading fields specified here. The origin of the read distance always refers to the front edge of the housing of the beam exit.

Reading field of BCL 8 with M optics




Figure 4.3: Reading field of BCL 8 S M ... with M optics (medium density)

Reading field of BCL 8 with N optics




Figure 4.4: Reading field of BCL 8 S N ... with N optics (high density)

5 Accessories/order codes

5.1 Accessories overview

Designation	Part no.	Short description
MA 8.1	50101699	MA 8.1 connection unit for BCL 8, RS 232 point-to-point connection, 1 switching input and 1 switching output, 24V DC
MA 8-01	50104790	MA 8-01 connection unit for BCL 8, RS 485 point-to-point connection, 1 switching input and 1 switching output, 24V DC
BT 8-0	50036196	Mounting device with dovetail
BT 300M.5	50118543	Mounting bracket, stainless steel
BTU 300M-D10	50117253	Sensor mounting bracket for rod \varnothing 10 mm or cheek 1.5 ... 4 mm
BTU 300M-D12	50117252	Sensor mounting bracket for rod \varnothing 12 mm or cheek 1.5 ... 4 mm
BTU 300M-D14	50117251	Sensor mounting bracket for rod \varnothing 14 mm or cheek 1.5 ... 4 mm
BTU D12M.5-150	50119323	Rod \varnothing 12 mm, length 150 mm, stainless steel
BTU D12M.5-250	50119324	Rod \varnothing 12 mm, length 250 mm, stainless steel
BTU D12M-D12-A090	50119323	90°-connector for 2 rods \varnothing 12 mm
BTU D12M-D12-B090	50119333	Mounting bracket for rods \varnothing 12 mm, system-side mounting bracket 2 x M6, hole spacing 27 mm ... 45 mm, diecast aluminum
BTP 300M-D10	50117827	Sensor protective cover for rod \varnothing 10 mm or cheek 1.5 ... 4 mm
BTP 300M-D12	50117826	Sensor protective cover for rod \varnothing 12 mm or cheek 1.5 ... 4 mm
BTP 300M-D14	50117825	Sensor protective cover for rod \varnothing 14 mm or cheek 1.5 ... 4 mm
Reflective tape no. 4 100 x 100 mm	50106119	Reflective tape as reflector for AutoReflAct operation
Sensor Studio	Download at www.leuze.com	Configuration software

Table 5.1: Accessories/order codes

5.2 MA 8.1 connection unit

The MA 8.1 connection unit is used to simplify the electrical installation of the BCL 8. The connection unit offers the following advantages over the installation of the BCL 8 as a stand-alone device:

- M12 socket for switching input and switching output
- M12 connector for RS 232 interface and voltage supply 24VDC
- M12 socket for connection of the BCL 8




Figure 5.1: Photo and dimensioned drawing of the MA 8.1 connection unit

5.2.1 Electrical connection MA 8.1




Figure 5.2: Electrical connection MA 8.1

5.2.2 MA 8.1 - PWR IN HOST/RS232 - voltage supply and RS 232

PWR IN HOST/RS232 (5-pin connector, A-coded)			
	Pin	Name	Comment
<p>M12 connector (A-coded)</p>	1	VIN	Positive supply voltage: +10 ... +30VDC
	2	TXD	RS 232 transmit data from the BCL 8 to the host
	3	GND	Supply voltage: 0VDC
	4	RXD	RS 232 receive data from the host to the BCL 8
	5	FE	Functional earth
	Thread	FE	Functional earth (housing)

Figure 5.3: MA 8.1 - Pin assignment PWR IN HOST/RS232

⚠ ATTENTION!

Degree of protection IP 67 is achieved only if the connectors and caps are screwed into place!

5.2.3 MA 8.1 - SW IN/OUT – switching input and switching output


SW IN/OUT (5-pin socket, A-coded)			
	Pin	Name	Comment
 <p>SW IN/OUT M12 socket (A-coded)</p>	1	VOUT	Voltage supply for sensor system (VOUT identical to VIN at PWR IN)
	2	SWOUT	Switching output
	3	GND	GND for the sensor system
	4	SWIN	Switching input
	5	FE	Functional earth
	Thread	FE	Functional earth (housing)

Figure 5.4: MA 8.1 - Pin assignment SW IN/OUT

⚠ ATTENTION!

⚠ Degree of protection IP 67 is achieved only if the connectors and caps are screwed into place!

NOTE

i The switching input/switching output are programmed using the **Sensor Studio** configuration software. For further information, see also Chapter 10.

⚠ ATTENTION!

⚠ If you use a sensor with a standard M12 connector, then please note the following:
 ↳ Use **only sensors** on which the **switching output does not lie on pin 2** or **sensor cables on which pin 2 is not assigned**. Otherwise, the switching output is not protected against feedback on the switching input. If the inverted sensor output lies on pin 2, erroneous behavior of the switching output will result.

Connecting the switching input / switching output

The MA 8.1 is provided with a switching input and a switching output. The connection of switching input / switching output is carried out in accordance with Figure 5.5.




Figure 5.5: Connection of the switching input/output of the MA 8.1

5.2.4 MA 8.1 - BCL - connecting the BCL 8 to the MA 8.1


BCL (5-pin socket, A-coded)			
	Pin	Name	Comment
 <p>M12 socket (A-coded)</p>	1	VIN	Supply voltage for BCL 8 +4.9 ... +5.4VDC
	2	TXD	RS 232 transmission line
	3	GND	Supply voltage: 0VDC
	4	RXD	RS 232 receiving line
	5	SWIN/ SWOUT	Programmable switching input/output of the BCL 8
	Thread	FE	Functional earth (housing)

Figure 5.6: MA 8.1 - Pin assignment BCL

⚠ ATTENTION!

Degree of protection IP 67 is achieved only if the connectors and caps are screwed into place!

The BCL 8 is connected to the MA 8.1 via the connection cable KB 008-1000/2000/3000 (AA/AR). The voltage supply is connected via the **PWR IN HOST/RS232** socket.

⚠ ATTENTION!

It is absolutely necessary to connect the functional earth, since all electrical interference (EMC coupling) is discharged via the functional earth connection.

5.3 Connection unit MA 8-01

The modular connection unit is an optional accessory when connecting a BCL 8 to an RS 485 interface. The RS 485 interface, the switching input and the switching output are all connected to the MA 8-01. It also supplies voltage to the BCL 8. The MA 8-01 connection unit offers the following advantages over the installation of the BCL 8 as a stand-alone device:

- M12 socket for switching input and switching output
- M12 connector for RS 485 interface and voltage supply 24VDC
- M12 socket for connection of the BCL 8




Figure 5.7: Pin assignment - MA 8-01

⚠ ATTENTION!

⚠ Degree of protection IP 67 is achieved only if the connectors and caps are screwed into place!

Electrical connection MA 8-01

Electrical data

Interface type	RS 485
Service interface	No MA 8-01 connected: RS 232 with default data format, 9600Bd, 8 data bits, no parity, 1 stop bit With MA 8-01 connected: RS 485 replaces RS 232
Switching input/output	1 switching input, 1 switching output, each is programmable Switching input: 10 ... 30VDC Switching output: $I_{max} = 500mA$ Output voltage = operating voltage
Operating voltage	10 ... 30VDC
Power consumption	Max. 0.5W

5.3.1 MA 8-01 - PWR IN HOST/RS485 - Voltage supply and RS 485



PWR IN HOST/RS485 (5-pin connector, A-coded)			
	Pin	Name	Comment
 <p>PWR IN HOST/RS485</p> <p>M12 connector (A-coded)</p>	1	VIN	Positive supply voltage: +10 ... +30VDC
	2	B (N)	RS 485 receive/transmit data B-line (N)
	3	GND	Supply voltage: 0VDC
	4	A (P)	RS 485 receive/transmit data A-line (P)
	5	FE	Functional earth
	Thread	FE	Functional earth (housing)

Figure 5.8: MA 8-01 - Pin assignment PWR IN HOST/RS485

⚠ ATTENTION!	
	Degree of protection IP 67 is achieved only if the connectors and caps are screwed into place!

5.3.2 MA 8-01 - SW IN/OUT - switching input and switching output





SW IN/OUT (5-pin socket, A-coded)			
	Pin	Name	Comment
 <p>SW IN/OUT</p> <p>M12 socket (A-coded)</p>	1	VOUT	Voltage supply for sensor system (VOUT identical to VIN at PWR IN)
	2	SWOUT	Switching output
	3	GND	GND for the sensor system
	4	SWIN	Switching input
	5	FE	Functional earth
	Thread	FE	Functional earth (housing)

Figure 5.9: MA 8-01 - Pin assignment SW IN/OUT

⚠ ATTENTION!	
	Degree of protection IP 67 is achieved only if the connectors and caps are screwed into place!

NOTE	
	The switching input/switching output are programmed via the parameters in the Sensor Studio configuration software. For further information, see also Chapter 10.

⚠ ATTENTION!	
	If you use a sensor with a standard M12 connector, then please note the following: <ul style="list-style-type: none"> Use only sensors on which the switching output does not lie on pin 2 or sensor cables on which pin 2 is not assigned. Otherwise, the switching output is not protected against feedback on the switching input. If the inverted sensor output lies on pin 2, erroneous behavior of the switching output will result.




Figure 5.10: Electrical connection MA 8-01

5.3.3 MA 8-01 - BCL - connecting the BCL 8 to the MA 8-01

BPS (5-pin socket, A-coded)			
	Pin	Name	Comment
<p>M12 socket (A-coded)</p>	1	VIN	Supply voltage for BCL 8 approx. +5.2VDC
	2	TXD	RS 232 transmission line
	3	GND	Supply voltage: 0VDC
	4	RXD	RS 232 receiving line
	5	SWIN/SWOUT	Programmable switching input/output of the BCL 8
	Thread	FE	Functional earth (housing)

Figure 5.11: MA 8-01 - Pin assignment BCL

⚠ ATTENTION!

⚠ Degree of protection IP 67 is achieved only if the connectors and caps are screwed into place!

The BCL 8 is connected to the MA 8-01 via the connection cable KB 008-1000/2000/3000 (AA/AR). The voltage supply is connected via the **PWR IN HOST/RS485** socket.

⚠ ATTENTION!

⚠ It is absolutely necessary to connect the functional earth, since all electrical interference (EMC coupling) is discharged via the functional earth connection.

5.3.4 Termination of the RS 485 interface

A permanently installed termination network is present in the MA 8-01. The network terminates the outgoing RS 485 data interface, as shown in Figure 5.12, and cannot be switched off.




Figure 5.12: Termination of the RS 485 interface in the MA 8-01

5.4 Mounting accessories

A variety of mounting devices are available for mounting the BCL 8. These are designed for rod or screw mounting (see also the Leuze Catalog, Series 8 Accessories).

Universal rod mounting system





Figure 5.13: Universal rod mounting system for BCL 8

6 Installation

6.1 Storage, transportation

⚠ ATTENTION!	
	Package the device for transport and storage in such a way that is protected against shock and humidity. Optimum protection is achieved when using the original packaging. Ensure compliance with the approved environmental conditions listed in the specifications.

Unpacking

↪ Check the packaging content for any damage. If damage is found, notify the post office or shipping agent as well as the supplier.

↪ Check the delivery contents using your order and the delivery papers:

- Delivered quantity
- Device type and model as indicated on the name plate
- Laser warning signs
- Brief manual

The name plates provide information as to what BCL type your device is. For specific information, please refer to Chapter 4.4.1.

BCL 8 name plate







BCL 8 type designation		<p>Leuze Laser CLASS 1 <small>D-73277 Owen www.leuze.com</small> BCL 8 SM 102 PN: 50038949 Man: FEB 2022 SN: 01234567890 SW: V 03.00 4.75-5.5V DC max.250mA class 2</p>	     <small>I.T.E. E206213</small>
------------------------	---	--	---

Figure 6.1: BCL 8 device name plate


↪ Save the original packaging for later storage or shipping.

If you have any questions concerning your shipment, please contact your supplier or your local Leuze sales office.

↪ Observe the applicable local regulations when disposing of the packaging materials.

Cleaning

↪ Clean the glass window of the BCL 8 with a soft cloth before mounting. Remove all packaging remains, e.g. carton fibers or Styrofoam balls.

⚠ ATTENTION!	
	Do not use aggressive cleaning agents such as thinner or acetone for cleaning the device.

6.2 Mounting

Accessories

A variety of mounting systems are available which you can order separately from Leuze (see Chapter 5.1 and Chapter 5.4).

Mounting the BCL 8

There are three basic mounting arrangements for the BCL 8 (see Chapter 4.3):

- using the dovetail fittings and the corresponding mounting accessory BT 8-0.
- using the mounting threads on the back- and underside of the devices.
- using the two \varnothing 4.4 mm through holes.

Mounting the MA 8.1 connection unit

You can mount the MA 8.1 connection unit according to your needs by using the two bore holes. Subsequently, connect the BCL 8 with the connection unit via the respective cable (see separate data sheet for MA 8.1).

6.2.1 Device arrangement

Selecting a mounting location

In order to select the right mounting location, several factors must be considered:

- size, orientation, and position tolerance of the bar codes on the objects to be scanned.
- the reading field of the BCL 8 in relation to the bar code module width.
- the resulting minimum and maximum read distance from the respective reading field (for specific information, please refer to Chapter 4.4).
- alignment of the bar code reader for avoiding reflections.
- distance between BCL 8 and host system with respect to the interface.

NOTE	
i	The best read results are obtained when <ul style="list-style-type: none"> • the reading distance lies in the middle area of the reading field. • there is no direct sunlight and extraneous light is avoided. • the bar code labels are of good print quality and have good contrast ratios. • you do not use high-gloss labels. • the bar code is moved past the reading window with an angle of rotation $>$ approx. 15°. • the laser beam is narrowed down for its respective reading task in order to avoid reflections on shiny components.

NOTE	
i	With front beam exit, the beam exit on the BCL 8 is nearly vertical to the reading window; with lateral beam exit, the beam exit is at 15° from vertical. The bar code label must be rotated by $> 10^\circ$ to avoid a total reflection of the laser beam in the case of glossy labels.




Figure 6.2: Definition of the BCL 8 reading angles

Mounting location

↳ When choosing the mounting location, observe the following:

- maintaining the required environmental conditions (temperature, humidity).
- possible soiling of the reading window due to liquids, abrasion by boxes, or packaging material residues.
- lowest possible chance of damage to the scanner by mechanical collision or jammed parts.
- possible extraneous light influence (no direct sunlight).

6.3 Connecting

⚠ ATTENTION!

⚠ The BCL 8 bar code reader is completely sealed and cannot be opened. Do not try to open the device under any circumstances, as this avoids both degree of protection IP 67 and the warranty.

- ↪ Before connecting the device, be sure that the supply voltage agrees with the value printed on the name plate.
- ↪ Connection of the device and maintenance work while under voltage must only be carried out by a qualified electrician.
- ↪ The power supply unit for the generation of the supply voltage for the BCL 8 and the corresponding connection units must have a secure electrical insulation according to IEC 60742 (PELV). For UL applications: only for use in class 2 circuits according to NEC.
- ↪ Take care to connect the protective conductor correctly to the housing screen. Fault-free operation is only guaranteed when the device is properly earthed.
- ↪ If faults cannot be cleared, the device should be switched off and protected against accidental use.

6.3.1 Connecting the BCL 8

BCL 8 pin assignment




Figure 6.3: BCL 8 pin assignment

Connection description

Pin 1	+5V DC	Operating voltage 5VDC
Pin 2	RS 232 TxD	TxD signal line of the RS232 interface
Pin 3	GND	Operating voltage 0VDC / reference ground
Pin 4	RS 232 RxD	RxD signal line of the RS232 interface
Pin 5	SW IN/OUT	Switching input or switching output
Thread	FE	Functional earth (housing)

Table 6.1: Wiring description BCL 8

6.3.2 Connecting the switching input/output

The BCL 8 is provided with a switching input **or** a switching output. You can configure the respective function (input or output) according to your requirements using the Sensor Studio program.

Switching input (default)

By means of the SW IN/OUT combined switching input/output connection, you can trigger a read process **in the standard setting** (low = active) with the connection SW IN/OUT (pin 5) and GND (pin 3). The 2.2 kΩ "pull-up" resistor must be connected externally (**connection version 1**, Figure 6.4).




Figure 6.4: Switching input for BCL 8 connection version 1 (standard setting)

With the "inverted" setting (high = active), you can trigger a read process by applying a voltage of +5 V DC (pin 1) at SW IN/OUT (pin 5) (connection version 2, Figure 6.5).




Figure 6.5: Switching input for BCL 8 connection version 2 (setting "inverted")

Switching output

The switching output connection between SW IN/OUT (pin 5) and GND (pin 3) can be activated in the scanner setup. In the basic setting, the SW IN/OUT switching output is switched to GND (pin 3) if a code is recognized.






Figure 6.6: Switching output BCL 8

⚠ ATTENTION!	
	Do not load the respective switching output of the BCL 8 with more than 20mA at +5 ... 30VDC!


NOTE	
	You can configure the switching input/switching output according to your requirements using the Sensor Studio program.

6.3.3 Cable lengths

The following maximum line lengths to be used must be observed:

Connection	Interface	Max. cable length	Shielding
BCL 8 direct	RS 232	< 3m	Required
BCL 8 – MA 8.1	RS 232	< 3m	Required
BCL 8 – MA 8-01	RS 232	< 3m	Required
MA 8.1 – host	RS 232	< 10m	Required
MA 8-01 – host	RS 485	< 25m	Required
Switching input/output		< 10m	Not necessary


Table 6.2: Cable lengths

<i>NOTE</i>	
	The RS 232 connection between BCL 8 and host must not exceed a total of 10m.

6.4 Disassembling, packing, disposing

Repacking

For later re-use, the device is to be packed so that it is protected against shocks and humidity. Optimum protection is achieved when using the original packaging.

<i>NOTE</i>	
	Electrical scrap is a special waste product! ↳ Observe the locally applicable regulations regarding disposal of the product.

7 Commissioning

7.1 Measures to be performed prior to the initial commissioning

- ↳ Before commissioning, familiarize yourself with the operation and configuration of the device(s).
- ↳ Before connecting the supply voltage, recheck all connections and ensure that they have been properly made.

7.2 Function Test

"Power On" test

After connecting the operating voltage, the BCL 8 performs an automatic "Power On" function test. Afterward, the green status LED on the top side of the BCL 8 lights up. Only then are any saved customer-specific settings active.

Interface

Proper function of the interface can be tested easiest in service operation using the service interface with the "BCLConfig" programming software and a notebook computer.

"Online" commands

Using the online commands, important device functions can be checked, e.g. proper functioning of the laser.

Problems

Should problems occur during device commissioning, refer first to Chapter 8.2. If a problem occurs that cannot be rectified even after checking all electrical connections and settings on the devices and on the host, please contact the closest Leuze service organization (see back page of this operating manual).

7.3 Setting the parameters

You have now commissioned the BCL 8. Usually, you will have to configure it before you can use it. Using the parameter options made available by the BCL 8, you may configure the bar code reader to suit your individual area of application. For instructions regarding the various setting options, refer to Chapter 9 or the online help of the Sensor Studio program.

To operate the BCL 8, it is normally sufficient to set code type and code length in accordance with the bar codes that are to be read. However, depending on the application, you will additionally activate the autoReflAct function and configure the switching inputs and outputs according to your requirements.

The code type and code length are usually set using the Sensor Studio program; see see chapter 9 "Configuration and diagnostics software - Sensor Studio".

The various parameter sets are explained briefly in the following Chapter 7.3.1, to understand what is happening during parameter setting.

The setting of the parameters then takes place in the "service" operating mode, which is described in Chapter 7.3.2.

7.3.1 Parameter sets

Factory default parameter set

This parameter set contains the default settings made ex works for all BCL 8 parameters. It is permanently stored in the ROM of the BCL 8. The parameter set with the factory settings is loaded into the memory of the BCL 8,

- the first time the device is commissioned after delivery;
- following the command "Factory Default" in the configuration program (online command 'PC20');
- if the check sums of the current parameter set are invalid.

Current parameter set

In this parameter set, the current settings for all device parameters are stored. When the BCL 8 is in operation, the parameter set is stored in the EEPROM of the BCL 8. The current set can be stored:

- by copying a valid parameter set from the host computer to the BCL 8;
- by an off-line setup using the BCLConfig configuration software and then subsequently copying to the BCL 8.

The current parameter set is loaded into the memory of the BCL 8:

- each time the supply voltage is connected;
- following a software reset (online command 'H').

The current parameter set is overwritten by the parameter set with the factory settings:

- by a parameter reset, see Page 59.

7.3.2 Service operating mode

Setting the required parameters is carried out easiest in the 'Service' operating mode. The operating mode Service provides the following defined operating parameters on the RS 232 interface, no matter how the BCL 8 is configured for standard operation:

- Transmission rate: 9600 baud
- No parity
- 8 data bits
- 1 stop bit
- Prefix: STX
- Postfix: CR, LF

Activate service interface

The service interface can be activated by holding a defined bar code label ("Service", see Figure 7.1) in front of the reading window during power-up (initialization phase).



Figure 7.1: Bar code label "Service"

While the laser switches on for approx. 1s after power-up, the "Service" label is to be held up in front of the bar code reader at a suitable read distance. When the device is in service mode, the status LED flashes orange.

Connecting

You can connect a PC or a terminal to the BCL 8 via the serial interface and configure the BCL 8 through this connection. The connection is made using an RS 232 connection cable that establishes the Rx/D, Tx/D and GND connections between PC and BCL 8.

If the BCL 8 is connected to a connection unit, you can establish the connection in the same way in front of the connection unit. For the respective pin assignments, please refer to the data sheet of the connection unit.





Figure 7.2: Connecting the RS 232 interface to a PC or terminal

8 Operation

<i>NOTE</i>	
	<p>↳ Please observe the notices for device arrangement in Chapter 6.2.1.</p> <p>↳ If possible, always trigger the laser scanner with the aid of commands, an external signal transmitter (photoelectric sensor) or the integrated AutoRefIAct function. Only then can you be certain whether a code has been read. If read, the code contents are transmitted; if not, the NoRead character is transmitted at the end of the reading gate).</p>

8.1 Display elements

On the BCL 8, you will find two LEDs that show the operational readiness and the reading state of the bar code reader (see Table 4.2 on page 13).

8.2 Error handling

Error, warning and status messages of the BCL 8 are transmitted via the RS 232 interface.

Types of errors

Errors are divided up into the following types:

- Warnings
- Serious errors

Warnings

Warnings indicate temporary operating faults which do not affect the proper functioning of the device.

Serious errors

Serious errors impair the proper functioning of the device. The device must be reinitialized.


Troubleshooting

Isolated warnings can be ignored, since the BCL 8 will continue to function properly.

Following a serious error, you should reinitialize the BCL 8. It will then usually again function properly. If a hardware problem is present, the BCL 8 will not reinitialize.

Warnings and errors which occur frequently can be corrected easiest using the BCLConfig software.

If you cannot correct faults and errors with the software, please contact a Leuze sales office or service center. For addresses, please refer to the back page of this operating manual.


<i>NOTE</i>	
	Please also observe the notices for diagnostics and troubleshooting in Chapter 12.3.

9 Configuration and diagnostics software - Sensor Studio

The *Sensor Studio* configuration software provides a graphical user interface for operation, configuration and diagnosis of the device via the RS 232 service interface.

A device that is not connected to the PC can be configured offline.

Configurations can be saved and reopened as projects for transferring back to the device at a later time.

NOTE	
	Only use the <i>Sensor Studio</i> configuration software for products manufactured by Leuze. The <i>Sensor Studio</i> configuration software is offered in the following languages: German, English, French, Italian and Spanish. The FDT frame application of <i>Sensor Studio</i> supports all languages; it is possible that not all languages are supported in the device DTM (Device Type Manager).

The *Sensor Studio* configuration software is designed according to the FDT/DTM concept:

- You make the individual configuration settings for the bar code reader in the Device Type Manager (DTM).
- The individual DTM configurations of a project can be called up via the frame application of the Field Device Tool (FDT).
- Communication DTM for bar code readers: *LeCommInterface*
- Device DTM for BCL 8 bar code reader

Procedure for the installation of the software and hardware:


- ↳ Install the *Sensor Studio* configuration software on the PC. Install the communication and device DTM.
- ↳ Communication and device DTMs are included in the *LeAnalysisCollectionSetup* installation package.
- ↳ Create the device DTM for BCL 8 in the project tree of the *Sensor Studio* FDT frame.
- ↳ Connect the bar code reader to the PC (see chapter "Connecting").
- ↳ Activate service interface on bar code reader (see chapter "Activate service interface").

9.1 System requirements


To use the *Sensor Studio* configuration software, you need a PC or laptop with the following specifications:

Operating system	Windows XP or higher (32 bit, 64 bit) Windows Vista Windows 7 Windows 8
Computer	Processor type: 1 GHz or higher Serial COM interface CD-ROM drive Main memory (RAM): at least 64 MB Keyboard and mouse or touchpad
Graphics card	At least 1024 x 768 pixels
Required hard disk capacity for <i>Sensor Studio</i> and communication DTM	35 MB

Table 9.1: System requirements for *Sensor Studio* installation

NOTE	
	Administrator privileges on the PC are necessary for installing <i>Sensor Studio</i> .


9.2 Installing Sensor Studio


NOTE	
	The installation files of the <i>Sensor Studio</i> configuration software must be downloaded from the Internet at www.leuze.com . For subsequent updates, you can find the most recent version of the <i>Sensor Studio</i> installation software on the Internet at www.leuze.com .

9.2.1 Downloading configuration software

- ↪ Call up the Leuze home page: **www.leuze.com**
- ↪ Enter the type designation or part number of the device as the search term.
- ↪ The configuration software can be found on the product page for the device under the Downloads tab.

9.2.2 Installing the Sensor Studio FDT frame

NOTE	
	First install the software! ↪ Do not yet connect the device to the PC. ↪ First install the software.

NOTE	
	If FDT frame software is already installed on your PC, you do not need to install <i>Sensor Studio</i> . You can install the communication DTM and the device DTM in the existing FDT frame. Communication and device DTMs are included in the <i>LeAnalysisCollectionSetup</i> installation package.

- ↪ Start the PC.
- ↪ Download the configuration software from the Internet to the PC (see chapter 9.2.1 "Downloading configuration software"). Unpack the installation package.
- ↪ Start the *SensorStudioSetup.exe* file.
- ↪ Follow the instructions on the screen.

9.2.3 Installing communication DTM and device DTM

Prerequisites:

- ✓ An FDT frame is installed on the PC.
- ↪ Start the *LeAnalysisCollection.exe* file from the installation package and follow the instructions on the screen.

9.2.4 Connecting device to PC


The device is connected to the PC via the RS 232 interface.

You need an RS 232 connection that establishes the RxD, TxD and GND connections between PC and device (see chapter "Connecting").

The +10 V DC ... +30 V DC voltage supply is to be fed in externally (see chapter 6.3 "Connecting").

9.3 Starting Sensor Studio

Prerequisites:

- ✓ The device has been mounted (see chapter 6.2 "Mounting") and connected (see chapter 6.3 "Connecting") correctly.
- ✓ The device is connected to the PC via the RS 232 interface (see chapter 6.3 "Connecting").
- ✓ The *Sensor Studio* configuration software is installed on the PC (see chapter 9.2 "Installing Sensor Studio").
- ↪ Start the *Sensor Studio* configuration software by double-clicking the [*Sensor Studio*] icon (.
- ⇒ The **mode selection** of the Project Wizard is displayed.
- ↪ Select the **Device selection without communication connection (offline)** configuration mode and click [Next].

⇒ The project wizard displays the device selection list of the configurable devices.




Figure 9.1: Device selection for the BCL 8

↪ Select **BCL 8** in the **device selection** and click [Next].

⇒ The device manager (DTM) of the connected bar code reader starts with the offline view for the *Sensor Studio* configuration project.

↪ Establish the online connection to the connected bar code reader.

⇒ In the *Sensor Studio* FDT frame, click the [Establish connection with device] button (▶).

⇒ In the *Sensor Studio* FDT frame, click the [Upload parameters to device] button (⬆).

⇒ The current configuration data is displayed in the device manager (DTM).





Figure 9.2: Configuration project: Device manager for BCL 8

↪ The menus of the *Sensor Studio* device manager (DTM) can be used to change or read out the configuration of the connected device.

⇒ The user interface of the *Sensor Studio* device manager (DTM) is largely self-explanatory.

⇒ The online help system provides information on the menu items and adjustment parameters. Select the **Help** menu item in the menu [?].

- ↵ Transfer the modified configuration parameters to the device.
 - ⇒ If a connection exists, click the [Download parameters to device] button () on the task bar.

9.4 Exiting Sensor Studio

After completing the configuration settings, close the *Sensor Studio* configuration software.

- ↵ Exit the program via **File > Exit**.
- ↵ Save the configuration settings as a configuration project on the PC.

9.5 Configuration parameters

In this chapter, you will find information and explanations regarding the configuration parameters of the device manager (DTM) for the bar code reader.

NOTE

i


This chapter does not include a complete description of the *Sensor Studio* configuration software. Complete information on the FDT frame menu and on the functions in the device manager (DTM) can be found in the online help system.

NOTE

i

The online help system displays information on the menu items and configuration parameters for each function. Select the **Help** menu item in the menu [?]

The *Sensor Studio* configuration software offers the following buttons in the CONFIGURATION menu:

-  : [Reset all parameters in the GUI to their factory default settings]
Resets all parameters in the graphical user interface to the factory settings.

9.5.1 Decode tab





Figure 9.3: Decode tab

Code table (CODE TABLE)	Here, the codes which are to be decoded are set. Codes which are not enabled are not decoded! Note: We recommend enabling only the code types which are to actually be read with the corresponding element number.
Element number	In the field Element number, up to three element entries may be entered. A range of permissible elements is indicated by a dash: e.g., 4-40 elements. To select a range, set the check mark under Interval mode. Up to three fixed element numbers with comma: e.g.: 8,13 elements Both are also possible, but the range must be specified first (select Interval mode): e.g.: 4-10,20 elements
Labels to be decoded (COMPLETENESS / Number of bar codes)	Here, the number of the bar codes to be decoded within a read cycle (one reading gate) is set.

NOTE

 If the code EAN128 is to be read, 3 additional characters must be set here for the code identifier.

Properties (Symbology Properties)	In the Symbology Properties window to the right of the respective code, the code-specific settings such as the check digit can be selected after Element number . Alternatively, you can select the property settings directly via the navigation tree with the [Symbologies] button. The properties can be individually set for each code type.
--------------------------------------	--




Figure 9.4: Standard settings of the **Properties** dialog box (SYMBOLOGY PROPERTIES)

Properties dialog box (Common Properties)





Figure 9.5: Standard settings of the **Properties** dialog box (COMMON PROPERTIES)

Quiet zone minimum size (in module widths) Quiet zone size	Quiet zone: the area to the left and right of the bar code Module: width of the narrowest line in the bar code According to code specifications, each bar code must have a quiet zone that is 10x as wide as the module of the bar code. Example: For a code with a module of 0.5 mm, there must be 5 mm of empty space to the left and right. By default, the scanner checks a quiet zone that is 7x greater than the module.
Reading reliability (Reading reliability (equal scans))	Under Reading security (equal scans) , it is possible to select how often a code must be decoded before the result is valid and output.
No time correlation between two identical scans	If this parameter is set, a gap between two identical labels is ignored and they are treated as a single label.
No position correlation between two identical scans	If this parameter is set, then the position of a bar code label in the reading beam is not taken into account. Identical labels are treated as a single label.

NOTE	
	In general, the remaining parameters must not be changed. In the worst case, this could corrupt the read result!

9.5.2 Output tab





Figure 9.6: Output tab (OUTPUT FORMAT)

Output header	Select from the options listed below. The output header is sent in a separate message before the read result.
Label header	The label header is set directly before the code data.
Label footer	The label footer is appended directly to the code data.
Message mode	Selects whether the bar codes read are sent in concatenation or separately as individual strings.

NOTE

 The structure of this message string is depicted symbolically in the preview window.

Text in the case of misreading (No read string)	This character is set for each unrecognized bar code. Multiple characters (=string) may be entered here. Up to 20 characters are possible.
---	--

Properties dialog box (Common Properties)

Set the desired formatting modes and formatting characters as necessary.




Figure 9.7: Properties dialog box (COMMON PROPERTIES)

Communication settings (Output channel)	Select from one of the options listed. Standard setting: <i>Host Interface</i>
Code output only if the codes/labels are different (Output different result only)	If you select this setting, a read result is only output within a reading gate opening if it is different to the previous read result. When rack reading, for example, this is used to set that the codes within adjacent samples are only output once.
Deletion of code output memory (Difference memory timeout)	Selecting this setting deletes the difference memory after the timeout time that can be set to the right of the checkbox has elapsed. After the timeout time has elapsed, a detected label is output a second time even if it was already directly detected once and the <i>Output different result only</i> checkbox is selected. The timeout time between the last reading and deletion of the difference memory can be set from 100 ms to 5000 ms.

9.5.3 Control tab




Figure 9.8: Control tab

Activation

Switching input 1 Function	See menu switching input
Auto-start after decoding Autostart after decode	In this mode, the scanner reads via an internal trigger signal with maximum performance. Note: Up to 100 codes per second can be transmitted.
Command character	The standard online character for the trigger start is the '+' character. This character cannot be changed.
Decode delay time	After the time set here has passed, the scanner automatically reactivates itself following a reading gate end (e.g. in combination with "Autostart after decoding"). Is normally used for test purposes.

Deactivation

Switching input 1 Function	See menu switching input
Immediately after the complete decoding result is available	If the setting is activated, the read result is output immediately after the bar code is decoded. If the setting is deactivated, the read result is sent only after the trigger signal is returned (= end of reading gate).
Command character	The standard online character for the trigger end is the '-' character. This character cannot be changed.
Time	If the code reader is activated, the reading gate is automatically closed by the code reader after this preset time has elapsed (e.g. for test purposes).
Scans without info	Following a successful read, the code reader waits for this number of scans (sequential scans with no read result) before it automatically deactivates itself.

9.5.4 Host interface tab




Figure 9.9: Host Interface tab

Select the desired baud rate, the stop bits, the data bits, the parity and various transmission modes here. The parameters are not active until these settings have been transferred to the code reader (standard procedure).

The desired acknowledgment settings are also to be set in this selection window.

Properties dialog box (Framing Protocol)





Figure 9.10: Standard settings of the Properties dialog box (FRAMING PROTOCOL)

Here, you can change the address settings and the protocol for sending and receiving.

NOTE	
	To be able to continue to communicate with a device following a parameter transfer, you may need to make appropriate adjustments to the communication properties of the device in the <i>Sensor Studio</i> configuration software.

9.5.5 Reference code tab




Figure 9.11: Reference Code tab

A reference code is bar code information which is stored in the memory of the scanner.

The reference code can be compared with the current decoded bar code in various modes and, thus, the switching output be set appropriately. For this purpose, the **switching output** must be set to **Reference Code Compare (Positive Reference Code Compare or Negative Reference Code Compare)** in the switching output (switch) menu.

One possibility to save the reference code is to manually enter the value in this menu. For further reference code teach-in options, see chapter 11 "Online commands".

Type	Selection of code type.
Contents (Info)	Contents of the reference code.
Comparison mode	Select here how the internally stored reference code is to be compared with the decoded result. For additional comparison possibilities, select the Properties dialog box.




Figure 9.12: Standard settings of the **Properties** dialog box (PROPERTIES)

9.5.6 Switching input tab

NOTE

The configuration options are identical for both switching inputs SWIN 1 and SWIN 2.





Figure 9.13: *Switching input* tab

Inverted	Here, the input level can be inverted
Debounce time	This time period must lapse until the trigger signal is regarded as valid.
Switch-on delay time	The trigger signal is passed on delayed by the specified time period.


Pulse duration	If the value is higher than "0": duration of the activation, regardless of how long the trigger signal has been present.
Switch-off delay	After the end of the trigger signal, the pulse is extended internally by this time period.
Function (Control)	Event that is started when the switching input is activated.

NOTE

 If switch-off delay is activated, the *pulse duration* parameter should be "0".

9.5.7 Switch tab

NOTE

 **Type and source of the danger**
The configuration options are identical for both switching outputs SWOUT 1 and SWOUT 2.




Figure 9.14: Switching output tab

Activation	Select the desired event which is to initiate the switching of the switching output here. Multiple events can also be simultaneously activated.
Deactivation	Shown here is the event which results in the switching output being reset if the set pulse duration has not yet expired. Multiple events can also be simultaneously activated.
Inverted	Here, the input level can be inverted
Pulse duration	Duration of the switching output pulse.
Pulse delay time	Length of time before the switching output is activated.

9.6 Diagnosis




Figure 9.15: *Diagnosis* tab

On the *Diagnosis* tab, you can send online commands to the device (see chapter 11 "Online commands") as well as display the read results and the device status.


Furthermore, buttons are available for the following functions:

- Layout of the screen display
- Deleting and printing the screen content
- General terminal settings

Version	Requests device version information (see chapter 11.1.1 "General online commands", command "V"). You can use this command to check whether the communication between PC and scanner is functional. If you do not receive an acknowledgment, please check the interface connections or the protocol.
Device Identification	Query of the serial number as well as the hardware and software versions.
Reset	Carries out a software reset. The device is restarted and reinitialized, leaving it in the same state as when the operating voltage is switched on.
Factory Default	Activates the device with the factory settings.
Activate Decoding Deactivate Decoding	Activates/deactivates decoding.
Start Continuous Decoding Stop Continuous Decoding	Starts/stops continuous decoding.

9.7 Firmware Reload

With the *Firmware Reload* tool (*MAINTENANCE* tab), you can load a different firmware into the device.

NOTE	
	You can find detailed information on the <i>Firmware Reload</i> tool in the information area of the FIRMWARE RELOAD dialog box and in the <i>Sensor Studio</i> online help.





Figure 9.16: Firmware Reload

- ↳ Load the file with the new firmware (**.mot*) to the Firmware Reload tool.
Click the [Browse] button.
A dialog for selecting the firmware file (**.mot*) opens.
- ↳ Once the firmware file is loaded to the *Firmware Reload* tool, click on the [Start Reload] button to load the new firmware into the device.
 - The device is connected via the serial interface specified under **Port**.
 - The *Firmware Reload* tool checks whether the new firmware is compatible with the device.
 - If the new firmware is compatible, the firmware is automatically installed in the device.
 - If the new firmware is not compatible with the device or is identical with the current firmware version, a dialog box for canceling or continuing the installation is displayed.

10 Starting up the device – Configuration

10.1 Measures to be performed prior to the initial commissioning

NOTE	
	<ul style="list-style-type: none"> ↪ Observe the notices for device arrangement (see chapter 6.2.1 "Device arrangement"). ↪ If possible, always trigger the bar code reader with the aid of commands or an external transducer (photoelectric sensor). <ul style="list-style-type: none"> ⇒ Only then can you be certain whether a code has been read (code contents are transmitted) or not (the NoRead character is transmitted at the end of the reading gate). ↪ Before commissioning, familiarize yourself with the operation and configuration of the device. ↪ Before connecting the operating voltage, recheck all connections and ensure that they have been properly made.

10.2 Starting the device

10.2.1 Power-on test

After connecting the operating voltage, the bar code reader performs an automatic "Power On" function test.

- During the start-up phase, the status LED flashes green.
- If the status LED is permanently lit green, the bar code reader is ready for operation. Any stored customer-specific settings are active.

10.2.2 Interface

Proper function of the interface can most easily be tested in service operation using the RS 232 interface with the *Sensor Studio* configuration software.

10.2.3 Online commands

Using the online commands, important device functions can be checked, e.g. reading activation (see chapter 11 "Online commands").

You can use online commands to directly send control and configuration commands to the device.

You can send online commands with a terminal program or with the *Sensor Studio* configuration software (see chapter 9 "Configuration and diagnostics software - Sensor Studio").

10.2.4 Problems

For information on how to proceed in the event of problems during commissioning of the devices, see chapter 12.3 "Diagnostics and troubleshooting".

If a problem occurs that cannot be rectified even after checking all electrical connections and settings on the devices and on the host, contact your responsible Leuze subsidiary or Leuze customer service (see chapter 12.4 "Service and support").

10.3 Starting up with factory settings

- ↪ Connect the operating voltage (+10 ... 30 V DC).
- ↪ If applicable, connect the switching input and the RS 232 interface.
- ↪ Switch on the operating voltage. The status LED must illuminate green.
- ↪ Activate the bar code reader via the switching input or with the '+' online command. The laser switches itself on.
- ↪ Hold the following sample bar code up to the bar code reader at a distance of approx. 100 mm.



- ↪ If reading is successful, the laser switches off. The read result is displayed on the monitor of the connected device.
- ↪ Deactivate the reading gate by removing the switching input signal or with the '-' online command.

10.4 Setting the configuration parameters

You commissioned the device. Usually, you will have to configure it before you can use it. With the configuration possibilities offered by the *Sensor Studio* configuration software or the device DTM, you can individually adapt the device to your specific application.

For instructions regarding the various setting options, refer to the online help or to the see chapter 9.5 "Configuration parameters".

- To operate the bar code reader, it is normally sufficient to set code type and code length in accordance with the bar codes that are to be read.
- Depending on the application, you can configure the switching input according to your requirements.

Configuration settings

The configuration settings are stored in the memory of the bar code reader in parameter sets. The various parameter sets are explained to understand what is happening during configuration parameter setting (see chapter 7.3.1 "Parameter sets").

- The setting of code type and code length is usually accomplished by using the *Sensor Studio* configuration software (see chapter 9 "Configuration and diagnostics software - Sensor Studio").
- You can set other configuration parameters as follows:
 - via the *Sensor Studio* configuration software using the buttons under **CONFIGURATION**.
 - via the internal setup of the bar code reader (start with the online command **CA**; see chapter 7.3.1 "Parameter sets")
 - via online commands (see chapter 11.1.3 "'Online' commands for parameter set operations").

10.4.1 Service mode

You can connect a PC or a terminal to the device via the RS 232 interface and configure the device through this connection (see chapter 6.3 "Connecting").

Setting the required parameters is carried out easiest in the "Service" operating mode.

The Service mode provides the following defined operating parameters on the RS 232 interface, no matter how the device is configured for process mode:

- Transmission rate: 9600 baud
- No parity
- 8 data bits
- 1 stop bit
- Prefix: STX
- Postfix: CR, LF

Activate service interface

The service interface can be activated by holding a defined bar code label in front of the reading window during power-up (initialization phase).



Figure 10.1: Bar code label "Service"

- ↳ While the laser switches on for approx. 1s after power-up, the "Service" label is to be held up in front of the bar code reader at a suitable read distance.
When the device is in "Service" mode, the status LED flashes orange.

10.4.2 Parameter sets

The configuration settings are stored in the memory of the bar code reader in parameter sets.

- Factory default parameter set
- Current parameter set

Factory default parameter set

This parameter set contains the factory-set default settings for all parameters of the bar code reader. It is permanently stored in the FLASH ROM of the bar code reader.

The parameter set with the default settings is loaded into the memory of the bar code reader:

- The first time the device is commissioned after delivery
- With the *Sensor Studio* configuration software via the [Factory Default] button in the **DIAGNOSIS** menu.
- After the online command **PC20** (see chapter 11.1.3 "'Online' commands for parameter set operations")
- If the checksums of the current parameter set are invalid

Current parameter set

In this parameter set, the current settings for all device parameters are stored. When the bar code reader is in operation, the current parameter set is stored in the EEPROM of the bar code reader.

The current parameter set is loaded into the main memory of the bar code reader with the **Copy parameter set** parameter set command (see chapter 11.1.3 "'Online' commands for parameter set operations").

You can save the current parameter set as follows:

- Copying a valid parameter set from the host computer into the bar code reader
- Off-line configuration using the *Sensor Studio* configuration software and then subsequently loading to the bar code reader

NOTE



To load the configuration into the bar code reader, select online mode.

11 Online commands

11.1 Overview of commands and parameters

Online commands can be used to send commands directly to the device for control and configuration. For this, the BCL 8 has to be connected to computer (host) via the serial interface.

For information on the transmission protocol, please see Chapter 7.3.2.

Using the **online commands** you can:

- control/decode the reading gate.
- read/write/copy parameters.
- carry out an automatic configuration.
- teach/set a reference code.
- call up error messages.
- call up statistical device information.
- carry out a software reset in order to reinitialize the device.

Syntax

Online commands consist of one or two ASCII characters followed by command parameters.

No separation characters may be entered between the command and the command parameter(s). Both small and capitalized letters can be used.

Example:

Command '**CA**': autoConfig function

Parameter '**+**': Activation

Transmitted is: '**CA+**'

Notation

Commands, command parameters and returned data are enclosed between single quotation marks ' ' in the text of this manual.

Most online commands are acknowledged by the BCL 8 and any requested data returned. For commands that are not acknowledged, command execution can be observed or monitored directly on the device.

11.1.1 General online commands

Software version number

Command	'V'
Description	Requests device version information
Parameter	None
Acknowledgment	Ex.: ' BCL 8 V 01.10 05.10.2006' The device type appears in the first line followed by the device's version number and date. The data which is actually displayed may vary from the values given here.

NOTE



You can use this command to check whether the communication to the connected computer is functional. If you do not receive an acknowledgment, please check the interface connections or the protocol.

Software reset

Command	'H'
Description	Carries out a software reset. The device is restarted and reinitialized, leaving it in the same state as when the supply voltage is switched on.
Parameter	No
Acknowledgment	'S' (start signal)

autoConfig


Command	'CA'
Description	Activates or deactivates the 'autoConfig' function. Certain label reading parameters are programmed automatically in the setup by the labels which the BCL 8 reads while the 'autoConfig' function is active.
Parameter	'+' Activates 'autoConfig' '/' Rejects the last code read '-' Deactivates 'autoConfig' and stores the decoded data in the current parameter set
Acknowledgment	'CSx' x Status '0' Valid 'CA' command '1' Invalid command '2' autoConfig could not be activated '3' autoConfig could not be deactivated '4' Result could not be deleted
Description	'xx yy zzzzzz' xx Code type of the read code '01' 2/5 Interleaved '02' Code 39 '06' UPC (A, E) '07' EAN '08' Code 128, EAN 128 '09' Pharmacode '10' EAN/UPC '11' Codabar '12' Code 93 yy No. of digits of the read code <u>zzzzz</u> Contents of the decoded label. The – appears if the label was not correctly read.

Manual definition of the reference code

Command	'RS'
Description	This command can be used to define a new reference code in the BCL 8 by means of direct input via the serial interface. The data is saved in the parameter set according to your input under reference code 1 or 2 and stored in the working buffer for direct further processing.
Parameter	'RSyvxxzzzzzzz' y, v, x and z are placeholders (variables) for the actual input. y Def. reference code no. '1' (Code 1) '2' (Code 2) v Storage location for reference code: '0' RAM+EEPROM '3' RAM only xx Def. code type (see Command 'CA') z Def. code information (1 ... 30 characters)
Acknowledgment	'RSx' x Status '0' Valid 'Rx' command '1' Invalid command '2' Insufficient memory for reference code '3' Reference code has not been saved '4' Reference code invalid
Example	Entry = 'RS130678654331' (Code 1 (1), RAM only (3), UPC (06), code information)

Teach-in

Command	'RT'
Description	This command enables a reference code to be defined quickly by reading an example label.
Parameter	'RTy' y Function '1' Defines reference code 1 '2' Defines reference code 2 '+' Activates the definition of reference code 1 or 2 '.' Ends the teach event
Acknowledgment	The BCL 8 first responds with the command 'RS' and corresponding status (see Command 'RS'). After a bar code has been read, it sends the result in the following format: 'RCyvxxzzzzz' y, v, x and z are placeholders (variables) for the actual input. y Def. reference code no. '1' (Code 1) '2' (Code 2) v Storage location for reference code '0' RAM+EEPROM '3' RAM only xx Def. code type (see Command 'CA') z Def. code information (1 ... 30 characters)

NOTE	
	With this function, only code types are recognized that are identified using the 'autoConfig' function or which were set in the set-up.

↳ After each reading via an 'RTy' command, explicitly switch off the function again since failure to do so will interfere with other commands as well as prevent execution of a new 'RTy' command.

Reading a reference code

Command	'RR'
Description	The command reads out the reference code defined in the BCL 8. If no parameters are specified, all defined codes are output.
Parameter	<Reference code number> '1' Reference code 1 '2' Reference code 2
Acknowledgment	If no reference codes are defined, the BCL 8 responds with the 'RS' command and corresponding status (see Command 'RS'). For valid codes, the output corresponds to the following format: RCyvxzzzzzz y, v, x and z are placeholders (variables) for the actual input. y Def. reference code no. '1' (Code 1) '2' (Code 2) v Storage location for reference code '0' RAM+EEPROM '3' RAM only xx Def. code type (see Command 'CA') z Def. code information (1 ... 30 characters)

Alignment mode

Command	'JP'
Description	This command is used for simplified mounting and alignment of the BCL 8 in static installation situations. After activating the function with 'JP+', the scanner continuously supplies status information to the serial interfaces. With this online command, the scanner is set to terminate the decoding after 100 successfully decoded labels and output the status information. Subsequently, the read process is reactivated automatically. As status, the output returns the following values: <ul style="list-style-type: none"> • scans which contain the valid label information on the basis of 100 scans, • the decoding result. These values can be used to determine the decoding quality. In addition to the output of the status information, the laser beam is used to display the reading quality. Depending on how many labels were able to be extracted, the duration of the laser's "off" time increases. If the reading quality is high, the laser beam flashes in brief, regular intervals. The worse the decoder decodes, the longer the pauses become during which the laser is switched off.
Parameter	'+': Starts the alignment mode. '-': Ends the alignment mode.
Acknowledgment	'xxxx_yyyyy' xxxx: "Scans since reading gate release" (scans_with info): Number of scans that contain valid label information. The maximum value is 100. yyyyy: Bar code information.

11.1.2 Online commands for system control

Activating sensor input

Command	'+'
Description	The command activates decoding.
Parameter	None
Acknowledgment	None

Deactivating sensor input

Command	'-'
Description	The command activates decoding.
Parameter	None
Acknowledgment	None

Activate switching output

Command	'OA'
Description	The command activates a selected switching output.
Parameter	'OAx': Activate switching output x Switching output No. '1' (output 1)
Acknowledgment	None

Deactivate switching output

Command	'OD'
Description	The command deactivates a selected switching output.
Parameter	'ODx': Deactivate switching output x Switching output No. '1' (output 1)
Acknowledgment	None

11.1.3 'Online' commands for parameter set operations

Definitions

- **<BCC type>** Type of checksum calculation.
 '0': No checksum
 '3': XOR checksum (mode 3)
- **<PS type>** Parameter set type
 '0': Current parameter set (data stored in the EEPROM (non-volatile))
 '1': Reserved
 '2': Standard parameter set (not changeable)
 '3': Operating values (data in the RAM, will be lost after reset)
- **<Status>** Mode of parameter processing
 '0': Does not perform a reset following the write operation; no other parameters follow.
 '1': Does not perform a reset following the write operation; other parameters follow.
 '2': Subsequently performs a reset, no other parameters follow.
- **<Start address>** Relative address of the parameter within the parameter set
- **<Para0L> <Para0H>... <Para122L> <Para122H>**:
 Parameter set data of the message. The sequence of the data is arranged identically to the BCL 8, i.e. when a word is transmitted, first the low byte is sent then the high byte. The parameter set data is converted for transmission from HEX format to a 2-byte-ASCII format. During the conversion, two ASCII characters - representing the lower and higher nibbles - are created for each HEX value.
 Example:

Decimal	Hex	Transmission
4660	0x1234	'1' '2' '3' '4' = 31h 32h 33h 34h

- Para0H = 31h, Para0L = 32h, Para1H = 33h, Para1L = 34h
 Taking into consideration the maximum message length and the remaining command parameters, a maximum of 123 bytes of parameter data (246 bytes of message data) can be transmitted in a single operation.
 Valid values: '0' ... '9', 'A' ... 'F'
- **<Acknowledgement>**:
 Acknowledgment of the transmitted message
 '0' valid transmission
 '1' invalid message
 '2' invalid length of message
 '3' invalid block check type
 '4' invalid block check checksum
 '5' invalid data length
 '6' invalid message data
 '7' invalid start address
 '8' invalid parameter set
 '9' invalid parameter set type

Copying parameter set

Command	'PC'
Description	The command copies complete parameter sets.
Parameter	'03' Copy parameters from the EEPROM into the RAM and initialize all associated functions '20' Copy standard parameters from the FLASH into the EEPROM and RAM and initialize all relevant functions '30' Copy parameters from the RAM into the EEPROM
Acknowledgment	'PSx' x Status '0' valid transmission '1' invalid message '2' invalid length of message '3' invalid block check type '4' invalid block check checksum '5' invalid data length '6' invalid message data '7' invalid start address '8' invalid parameter set '9' invalid parameter set type
Example	'PC20' loads the default parameters

Request parameter set from the BCL 8

Command	'PR'
Description	The command requests parameter data from the BCL 8. The <PS type> parameter indicates from which parameter set the data are to be transferred
Parameter	<BCC type> <PS type> <Start address> <Data length>
Acknowledgment	'PSx' x Status '0' valid transmission '1' invalid message '2' invalid length of message '3' invalid block check type '4' invalid block check checksum '5' invalid data length '6' invalid message data '7' invalid start address '8' invalid parameter set '9' invalid parameter set type
Example	'PR00102004' Beginning with address 102, four (004) bytes are read out and transmitted

Acknowledge parameter message

Command	'PS'
Description	The command acknowledges the received message and delivers an acknowledgment status which indicates whether the message was valid or invalid.
Parameter	'PSx' x Status '0' valid transmission '1' invalid message '2' invalid length of message '3' invalid block check type '4' invalid block check checksum '5' invalid data length '6' invalid message data '7' invalid start address '8' invalid parameter set '9' invalid parameter set type

Transfer parameters

Command	'PT'
Description	The command transmits parameter data starting from the defined address and stores them in an intermediate buffer. If the status indicates that further messages follow, these are also stored in the intermediate buffer before they are then stored under the corresponding parameter set type in the EEPROM. The transmission can optionally occur with a block check test of the message data.
Parameter	<BCC type> <PS type> <Status> <Start address> <Para0L> <Para0H> [... <Para122L>][<BCC>]
Acknowledgment	'PSx' x Status '0' valid transmission '1' invalid message '2' invalid length of message '3' invalid block check type '4' invalid block check checksum '5' invalid data length '6' invalid message data '7' invalid start address '8' invalid parameter set '9' invalid parameter set type
Example	'PT03203305' Address 33 (equal scans) is set to 5. Save in RAM with reset (immediate acceptance of the change and temporary storage)


12 Maintenance

12.1 General maintenance information

Usually, the BCL 8 bar code reader does not require any maintenance by the operator.

Cleaning

Should it become soiled, clean the glass window of the BCL 8 with a soft cloth.

<i>NOTE</i>	
	Do not use aggressive cleaning agents such as thinner or acetone for cleaning the device.

12.2 Repairs, servicing

Repairs to the device must only be carried out by the manufacturer.

↳ Contact your Leuze distributor or service organization should repairs be required.

For addresses, please refer to the back page of this operating manual.

12.3 Diagnostics and troubleshooting

Error	Possible error cause	Measures
Status LED: off	No supply voltage connected to the device.	Check supply voltage.
Status LED: flashing red	There is a device warning.	Query diagnostic data in the device and carry out the resulting measures or reset.
Status LED: continuous red light	Serious error, no function possible.	Internal device error, send in device for testing.
Status LED: flashing orange	Service operation is active.	Reset service operation, e.g. by resetting or interrupting the supply voltage
Decode LED	No error, see Table 4.2 on page 13.	
No communication possible	Incorrect wiring.	Check wiring.
	Wrong interface selected.	Select correct interface in the BCLconfig tool.
	Different protocol settings.	Check protocol settings in the BCL 8 and BCLconfig tool or switch the BCL 8 to service mode.
No code reading possible	Code reading not possible (quality).	Improve code quality! Entire code in laser line?
	Code is not enabled.	Check entries in the code table (type and length).
	Excessive reflections.	Increase angle of the laser beam to > 10° with respect to vertical.

12.4 Service and support

Service hotline

You can find the contact information for the hotline in your country on our website www.leuze.com under **Contact & Support**.

Repair service and returns


Defective devices are repaired in our service centers competently and quickly. We offer you an extensive service packet to keep any system downtimes to a minimum. Our service center requires the following information:

- Your customer number
- Product description or part description
- Serial number and batch number
- Reason for requesting support together with a description

Please register the merchandise concerned. Simply register return of the merchandise on our website www.leuze.com under **Contact & Support > Repair Service & Returns**.

To ensure quick and easy processing of your request, we will send you a returns order with the returns address in digital form.

What to do should servicing be required?

NOTE	
	<p>Please use this chapter as a master copy should servicing be required.</p> <p>↪ Enter the contact information and fax this form together with your service order to the fax number given below.</p>

Customer data (please complete)

Device type:	
Serial number:	
Firmware:	
Display messages	
Status of LEDs:	
Error description	
Company:	
Contact person/department:	
Phone (direct dial):	
Fax:	
Street / no.:	
ZIP code / City:	
Country:	

Leuze Service fax number:

+49 7021 573 - 199

12.5 Example bar code label types

Code type 01: Interleaved 2 of 5
Module 0.3



Code type 06: UPC-A
SC 2



Code type 02: Code 39
Module 0.3



Code type 07: EAN 8
SC 3



Code type 11: Codabar
Module 0.3



Code 128
Module 0.3



Code type 10: EAN 13 Add-on
SC 0 S



Code type 08: EAN 128
Module 0.3



Figure 12.1: Example bar code label types