
HRTU 418 RM/WM


▲ Leuze electronic


Ultrasonic sensors





- (available separately)
- Mounting systems
- Cable with M12 connector (K-D ...)


Dimensioned drawing












- Active surface Α
- Indicator diode Q1, Q2 в

Electrical connection



▲ Leuze electronic

HRTU 418 RM/WM

Specifications

Ultrasonic specifications

Operating range 1) Adjustment range Ultrasonic frequency Typ. opening angle Resolution Direction of beam

Reproducibility Switching hysteresis Temperature drift

Timing

Switching frequency Response time Delay before start-up

Electrical data

Operating voltage U_B²⁾ Residual ripple Bias current Switching output Function characteristics Output current Switching range adjustment

Indicators

Yellow LED Flashing yellow LED

Mechanical data

Housing Weight Ultrasonic transducer Connection type

Environmental data

Ambient temp. (operation/storage) Protective circuit ⁴⁾ VDE safety class Protection class Standards applied Fitting position Certifications

HRTU 418 ...-400-S12 25 ... 400mm 40 ... 400mm

75 300kHz 200kHz see diagrams 1mm HRTU 418RM/P...: straight, HRTU 418WM/P...: angular, 90° ± 1 mm 10mm ± 0.17%/K

10Hz 50ms 20 ms

20 … 30V DC (incl. \pm 10% residual ripple) \pm 10% of U_B ≤ 20 mA 2x PNP transistor switching in case of object recognition 300mA teach-in Q1: teach input (pin 2) connected to GND for 3 ... 6s teach-in Q2: teach input (pin 2) connected to GND for 6...9s

5Hz

100ms

HRTU 418...-700-S12

50 ... 700mm

700mm

output Q1, output Q2 teaching procedure

metal/brass nickel-plated 50g piezoceramic 3) M12 connector, plastic, 5-pin

-25°C ... +70°C/-40°C ... +85°C 1, 2, 3 ш IP 65 IEC 60947-5-2 any UL 508. C22.2 No.14-13 ^{2) 5)}

For the complete temperature range, measured object $\ge 20x20$ mm 1)

- For UL applications: for use in class 2 circuits according to NEC only 2) 3)
- The ceramic material of the ultrasonic transducer contains lead zirconium titanate (PZT)
- 1=short-circuit and overload protection, 2=polarity reversal protection, 3=wire break and inductive protection These proximity switches shall be used with UL Listed Cable assemblies rated 30V, 0.5A min, 4)
- 5)
- in the field installation, or equivalent (categories: CYJV/CYJV7 or PVVA/PVVA7)


Order guide


	Designation	Part No.
I,	HRTU 418RM/P-5220-400-S12	50109016
I,	HRTU 418WM/P-5220-400-S12	50109017
Ι,	HRTU 418RM/P-5220-700-S12	50109018
Ι,	HRTU 418WM/P-5220-700-S12	50109019

Diagrams

HRTU 418 ...-400-S12

Typ. response behaviour (object 20x20mm)





A Operating range

в Adjustment range

- Object С
- D Dead zone

Remarks

Operate in accordance with intended use!

- ✤ This product is not a safety sensor and is not intended as personnel
 - protection
- She product may only be put into operation by competent persons.
- \$ Only use the product in accor-
- dance with the intended use.

Temperature drift ± 0.17%/K

Operating range: 25 ... 400mm direction of beam: straight Operating range: 25 ... 400mm direction of beam: 90°

Operating range: 50 ... 700mm direction of beam: straight Operating range: 50 ... 700mm direction of beam: 90°

HRTU 418 RM/WM

Teach-in via input

- 1. Position measurement object at the desired distance.
- **2.** The respective teach function is activated by applying GND to the teach input (pin 2). The teach event is signalled by slow flashing of the LEDs.

Teach function	Teach phase / duration of the teach signal	LED Q1	LED Q2
Teach preparation	A/03s	off	off
switching output Q1	B/36s	flashes	off
switching output Q2	C/69s	off	flashes

3. To finish the teach event, disconnect the teach input from GND or switch it to $+U_B$ after the desired time. If the teach event has not completed after 9s, it begins again with phase B.

4. A successful teach event is signalled by the end of the flashing.

Error messages

LEDs which continuously flash fast signal an unsuccessful teach event (sensor not ready):

LED Q1	LED Q2	Error
flashes rapidly	switching state output Q2	teach switching output Q1 unsuccessful
switching state output Q1	flashes rapidly	teach switching output Q1 unsuccessful

Remedy:

- Disconnect sensor from voltage to restore the old values.
- Repeat teach event

▲ Leuze electronic

HRTU 418 RM/WM